

Grain Belt Swather



JD 4990 / 4995

2008 Operator's Manual



Important Notice

Review the sections of this manual regarding adjustments, settings, leveling, and table height before attempting to operate this header.

Without proper adjustment, damage to the header may occur.

Please wash this equipment after transporting

Honey Bee Manufacturing will not be responsible for any paint deterioration resulting from salt or harsh chemical corrosion if this equipment is not properly washed after transport. Use a mild soap solution, then rinse thoroughly.

If this equipment is stored near salted roadways through the winter months, it should be cleaned each spring.



This Page Is Intentionally Left Blank



Purchase Information

Dealers Name:	
Address:	
Phone:	()
Purchase Date:	
Model:	
Serial Number:	
Delivery Date:	

Modification Record		
Date	Modification	

Improvements

Honey Bee Manufacturing Limited is continually striving to improve its products. We reserve the right to make improvements or changes when it becomes practical and possible to do so, without incurring any obligation to make changes or additions to the equipment sold previously.



This Page Is Intentionally Left Blank



Warranty

Honey Bee Manufacturing Ltd. (Honey Bee) warrants your new Grain Belt swather to be free of defects in material and workmanship, under normal use and service. Obligations under this warranty shall extend for a period of 1 year (12 months) following the date of delivery to the original purchaser and shall be limited to, at the option of Honey Bee, replacement or repair of any parts found, upon inspection by Honey Bee, to be defective.

Warranty Claims

The purchaser claiming under this warranty shall report a warranty claim to his Authorized Dealer. The dealer shall complete the claim, on the prescribed form, for inspection by an authorized company representative. Warranty claims must be made within 60 days of warranty expiration.

Limitations of Liability

This warranty is expressly in lieu of all other warranties expressed or implied and all other obligations or liabilities on our part of any kind or character, including liabilities for alleged representations or negligence. We neither assume nor authorize any person to assume, on our behalf, any liability in connection with the subsequent sale of the Grain Belt swather.

This warranty shall not apply to any Grain Belt swather which has been altered outside the factory in any way so as in the judgment of Honey Bee to affect its operation or reliability, or which has been subject to misuse, neglect, or accident.

Operator's Manual

The purchaser acknowledges having received training in the safe operation of the Grain Belt swather and further acknowledges that Honey Bee does not assume any liability resulting from the operation of the Grain Belt swather in any manner other than described in this manual.



This Page Is Intentionally Left Blank



Honey Bee Manufacturing Ltd.

John Deere 4990-4995 WS Swather – Operator's Manual

Table of Contents

Purchase Information	3
Warranty	5
Warranty Claims	5
Limitations of Liability	5
Operator's Manual	5
Safety	13
Safety Terms	13
Shields	13
Operation and Maintenance Requirements	15
General Safety	15
Operating Safety – Good Practices	16
Maintenance Safety	16
Transport Safety	17
Before Transport Checklist	18
During Transport Checks	18
In-Field Checks	18
Storage	18
Safety Decal Locations	19
Safety-Related Decals	20
Installation Instructions	23
4990-4995 Swather Mounting Kit	24
Preliminary Information	25
JD Windrower Float Cylinder Recommendation with Honey Bee	25
Single Knife / Double Knife - Single Swath	25
Single Knife / Double Knife - Double Swath	25
Power Unit Preparation	26
Hydraulic Modifications - JD 4990 / 4995	26
Installing Quick Couplers	
Install Tilt Cylinder Quick Couplers	
Install the Windshield Guard	29
Install the Manual Lift Link (Standard Equipment)	
Install the Hydraulic Tilt Cylinder (Optional Equipment)	31
Installing the Needle Valve	36

Honey Bee Manufacturing Ltd.

Model Identification 39 New Model Wiring 40 Wiring Installation, Older Models 43 4990 Model Switch Installation 43 4995 Model Switch Installation 43 4990 and 4995 Models – Cab Modifications 46 Install Lift-Arm Extensions 48 Swather Preparation 49 Crop Divider Installation 49 Draper Installation 50 Installing the Strut Rollers 51 Installing the Strut Rollers 51 Installing the Strut Rollers 53 Connect Electrical and Hydraulic Systems 59 Store the Transport Hitch 60 Leveling the Swather 61 Calibrate the Hydraulic Pump 63 JD 4990-4995 Install the Flow-control Bracket 63 JD 4990-4995 Install the Flow-control Bracket 63 JD 4890-4995 WS Swather – New Wiring Configuration 66 JD 4890-4995 WS Swather – New Wiring Configuration 66 JD 4890-4990 WS Swather 68 Initial Start-up 69 Initial Start-up 69 Initial Start-up 69	Wiring Installation	39
New Model Wiring 40 Wiring Installation, Older Models. 43 4990 Model Switch Installation. 43 4995 Model Switch Installation. 43 4990 and 4995 Models – Cab Modifications. 46 Install Lift-Arm Extensions. 48 Swather Preparation. 49 Crop Divider Installation. 49 Draper Installation. 50 Install the Hose Holder. 52 Mounting the Strut Rollers. 51 Install the Hose Holder. 52 Mounting the Swather to the Windrower. 53 Connect Electrical and Hydraulic Systems. 59 Store the Transport Hitch. 60 Leveling the Swather. 61 Programming the Tachometer. 61 Calibrate the Hydraulic Pump. 63 JD 4990-4995 Install the Flow-control Bracket. 63 System Tests. 65 Hydraulics, Electrics, and Mechanical 65 Control Console Wiring Schematics. 66 JD 4895-4995 WS Swather – New Wiring Configuration. 66 JD 4895-4995 WS Swather – Original Configuration. 67 JD 4890-4	Model Identification	39
Wiring Installation, Older Models 43 4990 Model Switch Installation 43 4990 Adel Switch Installation 43 4990 and 4995 Models – Cab Modifications 46 Install Lift-Arm Extensions 48 Swather Preparation 49 Crop Divider Installation 49 Draper Installation 49 Draper Installation 50 Install the Hose Holder 52 Mounting the Strut Rollers 51 Install the Hose Holder 52 Mounting the Strut Rollers 51 Install the Hose Holder 52 Mounting the Swather to the Windrower 53 Connect Electrical and Hydraulic Systems 59 Store the Transport Hitch 60 Leveling the Swather 61 Programming the Tachometer. 61 Programming the Tachometer. 63 JD 4990-4995 Install the Flow-control Bracket 63 JD 4990-4995 WS Swather – New Wiring Configuration 66 JD 4895-4995 WS Swather – Original Configuration 66 JD 4890-4990 WS Swather 69 Initial Start-up 69	New Model Wiring	40
4990 Model Switch Installation 43 4995 Model Switch Installation 43 4990 and 4995 Models – Cab Modifications 46 Install Lift-Arm Extensions 48 Swather Preparation 49 Crop Divider Installation 49 Draper Installation 49 Draper Installation 49 Draper Installation 50 Installing the Strut Rollers 51 Installing the Strut Rollers 52 Mounting the Swather to the Windrower 53 Connect Electrical and Hydraulic Systems 59 Store the Transport Hitch 60 Leveling the Swather. 61 Programming the Tachometer. 61 Calibrate the Hydraulic Pump. 63 JD 4990-4995 Install the Flow-control Bracket 63 System Tests. 65 Hydraulics, Electrics, and Mechanical. 65 Optration 66 JD 4895-4995 WS Swather – New Wiring Configuration. 67 JD 4895-4995 WS Swather – Original Configuration. 67 JD 4890-4990 WS Swather. 69 F-N-R Lever Controls 70 <td>Wiring Installation, Older Models</td> <td>43</td>	Wiring Installation, Older Models	43
4995 Model Switch Installation 43 4990 and 4995 Models – Cab Modifications 46 Install Lift-Arm Extensions 48 Swather Preparation 49 Crop Divider Installation 49 Draper Installation 50 Installing the Strut Rollers 51 Installing the Strut Rollers 51 Install the Hose Holder 52 Mounting the Swather to the Windrower 53 Connect Electrical and Hydraulic Systems 59 Store the Transport Hitch 60 Leveling the Swather 61 Programming the Tachometer 61 Calibrate the Hydraulic Pump 63 JD 4990-4995 Install the Flow-control Bracket 63 System Tests 65 Hydraulics, Electrics, and Mechanical 65 Control Console Wiring Schematics 66 JD 4895-4995 WS Swather – New Wiring Configuration 67 JD 4895-4995 WS Swather 69 Initial Start-up 69 Initial Start-up 69 Initial Start-up 69 F-N-R Lever Controls 70 Bleedin	4990 Model Switch Installation	43
4990 and 4995 Models – Cab Modifications. 46 Install Lift-Arm Extensions. 48 Swather Preparation 49 Crop Divider Installation. 49 Draper Installation. 50 Installing the Strut Rollers. 51 Install the Hose Holder. 52 Mounting the Swather to the Windrower. 53 Connect Electrical and Hydraulic Systems. 59 Store the Transport Hitch. 60 Leveling the Swather. 61 Programming the Tachometer. 61 Calibrate the Hydraulic Pump 63 JD 4990-4995 Install the Flow-control Bracket. 63 System Tests. 65 Hydraulics, Electrics, and Mechanical. 65 Control Console Wiring Schematics. 66 JD 4895-4995 WS Swather – New Wiring Configuration. 67 JD 4890-4990 WS Swather – Mew Wiring Configuration. 67 JD 4890-4990 WS Swather – Original Configuration. 67 JD 4895-4995 WS Swather – Original Configuration. 67 JD 4890-4990 WS Swather. 68 Operation. 69 Initial Start-up. 69	4995 Model Switch Installation	43
Install Lift-Arm Extensions 48 Swather Preparation 49 Crop Divider Installation 49 Draper Installation 50 Installing the Strut Rollers 51 Installing the Strut Rollers 51 Install the Hose Holder 52 Mounting the Swather to the Windrower. 53 Connect Electrical and Hydraulic Systems 59 Store the Transport Hitch. 60 Leveling the Swather 61 Programming the Tachometer 61 Calibrate the Hydraulic Pump 63 JD 4990-4995 Install the Flow-control Bracket 63 JJD 4990-4995 Install the Flow-control Bracket 65 Control Console Wiring Schematics 66 JD 4895-4995 WS Swather – New Wiring Configuration 66 JD 4895-4995 WS Swather – Original Configuration 67 JD 4890-4990 WS Swather – Original Configuration 67 JD 4890-4990 WS Swather 68 Operation 69 Initial Start-up 69 F-N-R Lever Controls 70 Bleeding Air Out Of Reel Lift Circuit 71 Single Reel Lift Circ	4990 and 4995 Models – Cab Modifications	46
Swather Preparation 49 Crop Divider Installation 49 Draper Installation 50 Installing the Strut Rollers 51 Install the Hose Holder 52 Mounting the Swather to the Windrower 53 Connect Electrical and Hydraulic Systems 59 Store the Transport Hitch 60 Leveling the Swather 61 Programming the Tachometer 61 Calibrate the Hydraulic Pump 63 JD 4990-4995 Install the Flow-control Bracket 63 System Tests 65 Hydraulics, Electrics, and Mechanical 65 Control Console Wiring Schematics 66 JD 4895-4995 WS Swather – New Wiring Configuration 66 JD 4890-4990 WS Swather – Original Configuration 67 JD 480-4990 WS Swather 68 Operation 69 Initial Start-up 69 F-N-R Lever Controls 70 Bleeding Air Out Of Reel Lift Circuit 71 Single Reel Lift Circuit 72 36' Single Reel Lift Circuit 72 36' Single Reel Lift Circuit 72	Install Lift-Arm Extensions	48
Crop Divider Installation 49 Draper Installation 50 Installing the Strut Rollers 51 Install the Hose Holder 52 Mounting the Swather to the Windrower 53 Connect Electrical and Hydraulic Systems 59 Store the Transport Hitch 60 Leveling the Swather 61 Programming the Tachometer 61 Calibrate the Hydraulic Pump 63 JD 4990-4995 Install the Flow-control Bracket 63 System Tests 65 Hydraulics, Electrics, and Mechanical 65 Control Console Wiring Schematics 66 JD 4895-4995 WS Swather – New Wiring Configuration 67 JD 4890-4990 WS Swather – Original Configuration 67 JD 4890-4990 WS Swather – Original Configuration 67 JD 4890-4990 WS Swather 68 Operation 69 Initial Start-up 69 Initial Start-up 69 Initial Start-up 69 Initial Start-up 70 Bleeding Air Out Of Reel Lift Circuit 71 Single Reel Lift Circuit 72	Swather Preparation	49
Draper Installation 50 Installing the Strut Rollers 51 Install the Hose Holder 52 Mounting the Swather to the Windrower 53 Connect Electrical and Hydraulic Systems 59 Store the Transport Hitch 60 Leveling the Swather 61 Programming the Tachometer 61 Calibrate the Hydraulic Pump 63 JD 4990-4995 Install the Flow-control Bracket 63 System Tests 65 Hydraulics, Electrics, and Mechanical 65 Control Console Wiring Schematics 66 JD 4895-4995 WS Swather – New Wiring Configuration 66 JD 4895-4995 WS Swather – Original Configuration 67 JD 4890-4990 WS Swather 68 Initial Start-up 69 Initial Start-up 69 Initial Start-up 70 Bleeding Air Out Of Reel Lift Circuit 71 Single Reel Lift Circuit 72 36' Single Reel Lift Circuit 72 36' Single Reel Lift Circuit 72 Problems frequently encountered during start-up and break in period 74	Crop Divider Installation	49
Installing the Strut Rollers. 51 Install the Hose Holder. 52 Mounting the Swather to the Windrower. 53 Connect Electrical and Hydraulic Systems. 59 Store the Transport Hitch. 60 Leveling the Swather. 61 Programming the Tachometer. 61 Calibrate the Hydraulic Pump. 63 JD 4990-4995 Install the Flow-control Bracket. 63 System Tests. 65 Hydraulics, Electrics, and Mechanical. 65 Control Console Wiring Schematics. 66 JD 4895-4995 WS Swather – New Wiring Configuration. 66 JD 4895-4995 WS Swather. 68 Operation. 69 Initial Start-up. 69 F-N-R Lever Controls. 70 Bleeding Air Out Of Reel Lift Circuit. 71 Single Reel Lift Circuit. 72 36' Single Reel Lift Circuit. 72 36' Single Reel Lift Circuit. 72 Problems frequently encountered during start-up and break in period. 74 Full Dismount. 75	Draper Installation	
Install the Hose Holder.52Mounting the Swather to the Windrower.53Connect Electrical and Hydraulic Systems.59Store the Transport Hitch.60Leveling the Swather.61Programming the Tachometer.61Calibrate the Hydraulic Pump.63JD 4990-4995 Install the Flow-control Bracket.63System Tests.65Hydraulics, Electrics, and Mechanical.65Control Console Wiring Schematics.66JD 4895-4995 WS Swather – New Wiring Configuration.66JD 4895-4995 WS Swather – Original Configuration.67JD 4890-4990 WS Swather.68Operation.69Initial Start-up.69F-N-R Lever Controls.70Bleeding Air Out Of Reel Lift Circuit.71Single Reel Lift Circuit.7236' Single Reel Lift Circuit.72Store Lift Circuit.72Yroblems frequently encountered during start-up and break in period.74Full Dismount.75	Installing the Strut Rollers	51
Mounting the Swather to the Windrower. 53 Connect Electrical and Hydraulic Systems. 59 Store the Transport Hitch. 60 Leveling the Swather. 61 Programming the Tachometer. 61 Calibrate the Hydraulic Pump. 63 JD 4990-4995 Install the Flow-control Bracket. 63 System Tests. 65 Hydraulics, Electrics, and Mechanical. 65 Control Console Wiring Schematics. 66 JD 4895-4995 WS Swather – New Wiring Configuration. 66 JD 4895-4995 WS Swather – Original Configuration. 67 JD 4890-4990 WS Swather. 68 Operation. 69 Initial Start-up. 69 F-N-R Lever Controls. 70 Bleeding Air Out Of Reel Lift Circuit. 71 Single Reel Lift Circuit. 71 Double Reel Lift Circuit. 72 36' Single Reel Lift Circuit. 72 Problems frequently encountered during start-up and break in period. 74 Full Dismount. 75	Install the Hose Holder	52
Connect Electrical and Hydraulic Systems59Store the Transport Hitch60Leveling the Swather61Programming the Tachometer61Calibrate the Hydraulic Pump63JD 4990-4995 Install the Flow-control Bracket63System Tests65Hydraulics, Electrics, and Mechanical65Control Console Wiring Schematics66JD 4895-4995 WS Swather – New Wiring Configuration66JD 4895-4995 WS Swather – Original Configuration67JD 4890-4990 WS Swather69Initial Start-up69Initial Start-up69F-N-R Lever Controls70Bleeding Air Out Of Reel Lift Circuit71Single Reel Lift Circuit7236' Single Reel Lift Circuit72Problems frequently encountered during start-up and break in period.74Full Dismount75	Mounting the Swather to the Windrower	53
Store the Transport Hitch. 60 Leveling the Swather. 61 Programming the Tachometer. 61 Calibrate the Hydraulic Pump. 63 JD 4990-4995 Install the Flow-control Bracket. 63 System Tests. 65 Hydraulics, Electrics, and Mechanical. 65 Control Console Wiring Schematics. 66 JD 4895-4995 WS Swather – New Wiring Configuration. 66 JD 4895-4995 WS Swather – Original Configuration. 67 JD 4890-4990 WS Swather. 68 Operation. 69 Initial Start-up. 69 F-N-R Lever Controls. 70 Bleeding Air Out Of Reel Lift Circuit. 71 Single Reel Lift Circuit. 71 Single Reel Lift Circuit. 72 36' Single Reel Lift. 72 Problems frequently encountered during start-up and break in period. 74 Full Dismount. 75	Connect Electrical and Hydraulic Systems	
Leveling the Swather61Programming the Tachometer.61Calibrate the Hydraulic Pump.63JD 4990-4995 Install the Flow-control Bracket.63System Tests.65Hydraulics, Electrics, and Mechanical.65Control Console Wiring Schematics.66JD 4895-4995 WS Swather – New Wiring Configuration.66JD 4895-4995 WS Swather – Original Configuration.67JD 4890-4990 WS Swather68Operation.69Initial Start-up.69F-N-R Lever Controls.70Bleeding Air Out Of Reel Lift Circuit.71Single Reel Lift Circuit.7236' Single Reel Lift Circuit.72Problems frequently encountered during start-up and break in period.74Full Dismount.75	Store the Transport Hitch	60
Programming the Tachometer.61Calibrate the Hydraulic Pump.63JD 4990-4995 Install the Flow-control Bracket.63System Tests.65Hydraulics, Electrics, and Mechanical.65Control Console Wiring Schematics.66JD 4895-4995 WS Swather – New Wiring Configuration.66JD 4895-4995 WS Swather – Original Configuration.67JD 4890-4990 WS Swather.68Operation.69Initial Start-up.69F-N-R Lever Controls.70Bleeding Air Out Of Reel Lift Circuit.71Single Reel Lift Circuit.7236' Single Reel Lift.72Problems frequently encountered during start-up and break in period.74Full Dismount.75	Leveling the Swather	61
Calibrate the Hydraulic Pump.63JD 4990-4995 Install the Flow-control Bracket.63System Tests.65Hydraulics, Electrics, and Mechanical.65Control Console Wiring Schematics.66JD 4895-4995 WS Swather – New Wiring Configuration.66JD 4895-4995 WS Swather – Original Configuration.67JD 4890-4990 WS Swather.68Operation.69Initial Start-up.69F-N-R Lever Controls.70Bleeding Air Out Of Reel Lift Circuit.71Single Reel Lift Circuit.7236' Single Reel Lift Circuit.72Problems frequently encountered during start-up and break in period.74Full Dismount.75	Programming the Tachometer	61
JD 4990-4995 Install the Flow-control Bracket	Calibrate the Hydraulic Pump	63
System Tests. .65 Hydraulics, Electrics, and Mechanical. .65 Control Console Wiring Schematics. .66 JD 4895-4995 WS Swather – New Wiring Configuration. .66 JD 4895-4995 WS Swather – Original Configuration. .67 JD 4890-4990 WS Swather. .68 Operation. .69 Initial Start-up. .69 F-N-R Lever Controls. .70 Bleeding Air Out Of Reel Lift Circuit. .71 Single Reel Lift Circuit. .71 Double Reel Lift Circuit. .72 36' Single Reel Lift. .72 Problems frequently encountered during start-up and break in period. .74 Full Dismount. .75	JD 4990-4995 Install the Flow-control Bracket	63
Hydraulics, Electrics, and Mechanical. .65 Control Console Wiring Schematics. .66 JD 4895-4995 WS Swather – New Wiring Configuration. .66 JD 4895-4995 WS Swather – Original Configuration. .67 JD 4890-4990 WS Swather. .68 Operation. .69 Initial Start-up. .69 F-N-R Lever Controls. .70 Bleeding Air Out Of Reel Lift Circuit. .71 Single Reel Lift Circuit. .71 Double Reel Lift Circuit. .72 36' Single Reel Lift. .72 Problems frequently encountered during start-up and break in period. .74 Full Dismount. .75	System Tests	65
Control Console Wiring Schematics66JD 4895-4995 WS Swather – New Wiring Configuration66JD 4895-4995 WS Swather – Original Configuration67JD 4890-4990 WS Swather68Operation69Initial Start-up69F-N-R Lever Controls70Bleeding Air Out Of Reel Lift Circuit71Single Reel Lift Circuit71Double Reel Lift Circuit7236' Single Reel Lift72Problems frequently encountered during start-up and break in period74Full Dismount75	Hydraulics, Electrics, and Mechanical	65
JD 4895-4995 WS Swather – New Wiring Configuration	Control Console Wiring Schematics	66
JD 4895-4995 WS Swather – Original Configuration	JD 4895-4995 WS Swather – New Wiring Configuration	66
JD 4890-4990 WS Swather	JD 4895-4995 WS Swather – Original Configuration	67
Operation.69Initial Start-up.69F-N-R Lever Controls.70Bleeding Air Out Of Reel Lift Circuit.71Single Reel Lift Circuit.71Double Reel Lift Circuit.7236' Single Reel Lift.72Problems frequently encountered during start-up and break in period.74Full Dismount.75	JD 4890-4990 WS Swather	68
Initial Start-up. 69 F-N-R Lever Controls. 70 Bleeding Air Out Of Reel Lift Circuit. 71 Single Reel Lift Circuit. 71 Double Reel Lift Circuit. 72 36' Single Reel Lift. 72 Problems frequently encountered during start-up and break in period. 74 Full Dismount. 75	Operation	69
F-N-R Lever Controls. 70 Bleeding Air Out Of Reel Lift Circuit. 71 Single Reel Lift Circuit. 71 Double Reel Lift Circuit. 72 36' Single Reel Lift. 72 Problems frequently encountered during start-up and break in period. 74 Full Dismount. 75	Initial Start-up	69
Bleeding Air Out Of Reel Lift Circuit. 71 Single Reel Lift Circuit. 71 Double Reel Lift Circuit. 72 36' Single Reel Lift. 72 Problems frequently encountered during start-up and break in period. 74 Full Dismount. 75	F-N-R Lever Controls	70
Single Reel Lift Circuit	Bleeding Air Out Of Reel Lift Circuit	71
Double Reel Lift Circuit	Single Reel Lift Circuit	71
36' Single Reel Lift	Double Reel Lift Circuit	72
Problems frequently encountered during start-up and break in period74 Full Dismount	36' Single Reel Lift	72
Full Dismount	Problems frequently encountered during start-up and break in period	74
	Full Dismount	75

Honey Bee Manufacturing Ltd.

Self Storing Hitch – Transport Position	76
Install Transport Axle	77
Reel	81
REEL POSITION	81
Fore/Aft Adjustment (Manual Version)	81
Reel Arm Leveling and Height Adjustment	82
Center Arm Leveling	83
Optional Hydraulic Fore & Aft	84
Reel Centering	85
Reel Drive	86
Reel Speed Adjustment	87
Universal UII Pick up Reel	88
Tine Pitch Adjustment	88
Minimum Reel Height	
Reel Position in "Down" Crops	89
Reel Position in Standing Crops	
Reel Speed	89
Lubrication - Reel Shaft Bearings	90
Reel Tines	90
Control Rings	91
Hart-Carter Reel (HCC)	91
Placement of the Reel on the Swather	91
HCC Check Points before Operation	93
Tine Pitch Adjustment	93
Reel Speed	94
Crop Control at Ends of the Swather	94
Draper	95
Draper Installation	
Tension	
Alignment	96
Idler Roller Tracking Adjustment	97
Drive Roller Tracking Adjustment	97
Draper Speed	
Double Swath Option	
Centre Single Swath	

Honey Bee Manufacturing Ltd.

Draper Splicing	
Idler Roller Removal	101
Drive Roller Removal	102
Removing Draper motor	103
Installing Draper Motor	103
Draper Deck Maintenance:	104
Cutting System	105
Removing the Knife	106
Guards	106
Sickle Sections	106
Replace a Section:	106
Knife Drive/Knife Head	108
Connector Bar	109
Overlap Kit	110
Repair Broken Knife Back	111
Knife Speed Sensor	112
Monitoring Knife Speed	112
Leveling	113
Forward Angle Adjustment	113
Production Swather - Hydraulic Tilt Kit	113
Table Angle	114
Table Leveling	115
Preparing the table for further Leveling	117
JD Windrower Float Cylinder Recommendation with Honey Bee	119
Single Knife / Double Knife - Single Swath	119
Single Knife / Double Knife - Double Swath	119
Hydraulics	121
Flow Divider	121
Hydraulic Connection Points	122
Operating Pressure - Knife Circuit	122
Checking or Adjusting Knife Relief Pressure	122
Flow Control Setting	123
Draper Relief Pressure	124
Adjusting Relief Pressure	124
Reel Speed Control	125

Honey Bee Manufacturing Ltd.

Additional Reel Speed Control	
Reel Relief Pressure	125
Adjusting the Relief Pressure	126
Return Line Filter	126
Hydraulic System Schematics	127
Draper Drive	127
Fore and Aft	131
Knife Drive	134
Reel Lift	137
Reel Drive	141
Upper Tube Hydraulics	145
Optional Equipment	149
Caster Gauge Wheels	149
Gauge Wheel Height Adjustment	150
End Strut Gauge Wheels	151
Vertical Crop Cutters	151
Cross Auger	152
Double Swath Option – 21, 25, 30 and 36 Foot Tables	153
Junior Deck Option – For Swathers With the Double Swath Option	155
Steel Skid Plates	155
Dimensions – Single swath delivery	156
Dimensions – Double Swath Delivery	157
Draper Extension for Swathing	158
Hay Guard / Short Crop Guard	159
SCH Crop Lifters	160
Hydraulic Tilt Cylinder Assembly	161
Windrow Type	163
Windrow Formations	163
Ground Speed	163
Stubble Height	163
Lubrication and Maintenance	165
Maintenance Related Decals	166
Troubleshooting	167
Reel	167

Honey Bee Manufacturing Ltd.

Knife	168
Draper	171
Decks	171
Hydraulic Oil	172
Leveling	173
Table Angle	173
Raising and lowering the Swather	173
Lift and Float Systems	173
Specifications/Features	175
Weights	175
Knife Drive Availability	175
Technical Specifications	176
Options	177
Included in the Standard Swather	177
Bolt Torque	178
Hydraulic Fitting Torque	179
Tightening Flare Type Tube Fittings	179
Hydraulic Fitting Torque Table	179
Tightening O-ring Fittings	180
Lighting	181
Transport Lights:	181
Warning Lights:	181
Light Wiring	184



Safety

In this manual the safety conventions used are as follows:

Safety Terms

	Indicates an imminently hazardous situation that if not avoided, will result in death or serious injury. This signal word is to be limited to the most extreme situations, typically for machine components that, for functional purposes, cannot be guarded.	
	Indicates a potentially hazardous situation that, if not avoided, could result in death or serious injury, and includes hazards that are exposed when guards are removed. It may also be used to alert against unsafe practices.	
	Indicates a potentially hazardous situation that, if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices.	
ATTENTION:	Warns of potential damage to the machine if procedures are not followed.	
IMPORTANT:	Provides instructions to help you avoid unnecessary strain on, or possible damage to the machine.	

Shields

Shields are provided to protect you from injury. Make sure they are in place and secured before starting the machine.

NOTE:	Names given here for parts of the swather are those in use at the time
	of design.

Honey Bee Manufacturing Ltd.



John Deere 4990-4995 WS Swather – Operator's Manual

WARNING:	THIS MACHINE IS POWERED AND RUN BY HYDRAULIC OIL UNDER HIGH PRESSURE. CAUTION MUST BE TAKEN AROUND THE MACHINE BECAUSE HIGH-PRESSURE HYDRAULIC FLUID CAN PENETRATE THE SKIN CAUSING SERIOUS INJURY AND POSSIBLY DEATH.
	WHEN LOOKING FOR A HYDRAULIC LEAK, ALWAYS HOLD A PIECE OF CARDBOARD UP TO THE SUSPECTED AREA. NEVER USE YOUR UNPROTECTED HANDS TO LOCATE A LEAK.
	ALWAYS WEAR EYE PROTECTION, GLOVES AND LONG SLEEVE CLOTHING WHEN WORKING NEAR HYDRAULICS. SINCE SMALL LEAKS CAN BE INVISIBLE.



Figure 1: Hydraulic Hazard Warning

YOU CAN REDUCE THIS HAZARD by relieving system pressure before disconnecting hydraulic lines. Tighten all connections to specifications before re-applying pressure.





Operation and Maintenance Requirements

YOU are responsible for the safe operation and maintenance of your Honey Bee Swather. YOU must ensure that you and anyone else, who is going to operate, maintain or work around the swather be familiar with the operating and maintenance procedures and related SAFETY information contained in this manual.

Remember YOU are the key to safety. Good safety practices not only protect you but also the people around you. Make these practices a working part of your safety program. Most accidents can be prevented. Do not risk injury or death by ignoring good safety practices.

Operating instructions for this swather should be reviewed by each operator at least once a year per OSHA regulations 1928.57. The meaning of each decal should be understood, and their locations should be known prior to operating the swather.



Watch for this symbol, both in this manual and on the swather. It will identify hazards that could cause injury or death.

General Safety

- 1. Maintain moving parts, hydraulics and motors clear of chaff and straw to prevent the possibility of fire.
- 2. Carry a multipurpose fire extinguisher in the power unit and know how to use it. Check the extinguisher regularly and keep it fully charged.
- 3. Provide a first aid kit in the cab for emergencies and know how to use it.
- 4. Do not wear loose clothing or jewelry around moving parts.
- 5. Wear appropriate protective gear. This list includes but is not limited to:
 - a. A hard hat
 - b. Protective shoes with slip-resistant soles
 - c. Protective glasses or goggles
 - d. Leather gloves
 - e. Hearing protection
 - f. Respirator or filter mask
- 6. Do not allow any one to ride on the swather while it or the windrower is in motion.
- 7. Make certain that the park brake is engaged, and the power unit is in neutral before starting the engine.

8. Clear the area of bystanders, especially small children before starting the power unit.

- 9. Do not allow anyone to operate the swather who has not been instructed in how to operate the machine.
- 10. All operators should familiarize themselves with the SAFETY section in the Power unit Operators Manual.
- 11. Some pictures or illustrations in this manual may not show protective shields in place. This is done in order to make important components visible. Make certain that all protective shields are secured in place before operating the machine.

Operating Safety – Good Practices

Honey Bee

- 1. STOP the power unit, engage the parking brake, place the power unit in neutral, remove the key, and wait until all moving parts stop before leaving the cab.
- 2. Either lower both the table and the reel, or raise the swather to its full height and set the platform lock before servicing the swather. If working under reel, set the reel cylinder locks. A loss of hydraulic pressure could cause the swather and reel to lower unexpectedly.
- 3. NEVER operate machinery while tired, sick or otherwise impaired.
- 4. Do not operate the swather in crowded or confined areas.



DO NOT stand between the power unit and the swather while raising or lowering the swather.

Maintenance Safety

- 1. Before undertaking any maintenance, engage the park brake, either lower the reel and swather, or raise and lock the swather using the platform lock and shut off the engine of the power unit. Make sure there is no pressure being supplied to the hydraulic lines.
- 2. Hydraulic leaks can penetrate the skin causing serious injuries. Small leaks can be invisible and are the most dangerous. Use some kind of object, such as cardboard, to find the leak -- DO NOT USE YOUR HAND.
- 3. Ensure that all the pressure is released from the hydraulic lines before starting a repair. Replace or repair damaged hoses immediately.



4. Care should be taken when maintaining the knife. Sickle sections are very sharp and can easily cause severe injury. Use heavy leather or canvas gloves when working with the knife. Always ensure everyone is well clear before moving the knife, manually or under power.

Transport Safety

- 1. Transport the swather with the SMV (Slow Moving Vehicle) sign displayed on the rear of the swather and use your hazard lights if the law permits. Check local road laws before transporting.
- 2. When transporting the swather on roads, always be aware of the width of the swather.
- 3. For long distance transporting completely install the full transport assembly. (see dismount section).
- 4. Do not transport the machine at night, at dawn, or at dusk.
- 5. Ensure hitch is firmly attached and secured with hitch pins before moving.
- 6. Attach the hitch safety chain before moving.
- 7. Do not exceed 40 kph (25 mph) during transport.
- 8. Ensure you display the Slow Moving Vehicle sign during transport on roadways.
- 9. Make sure that all lighting is properly installed and operational as described in the Lighting chapter of this manual.



Figure 2: Slow Moving Vehicle Sign

Before Transport Checklist

- 1. Do a complete walk-around and check to be sure there are no loose parts.
- 2. Check:

a. all reel mounting, reel drive and adapter assembly bolts to be sure no bolts/nuts are loose.

b. wheel bolts to make sure they are tight.

- c. transport tire pressure. Recommended pressure is 50 psi (345 kPa)
- d. spindle and hitch lock pins to make sure they are in place and securely fastened.
- 3. Inspect all hoses. Ensure they are secured so they will not pinch or drag during transport.
- 4. Ensure hitch tongue and safety chain are securely fastened securely to the swather and to the transporting vehicle.

During Transport Checks

- 1. Stop after the first 5 to 10 kilometers (2 to 6 miles) and check to make sure the wheel bolts are tight and the wheel hubs are not hot. Make periodic checks every 50 to 60 km (30 -40 miles) if towing the swather long distances.
- 2. Check the hitch bolt and safety chain periodically to make sure they are secure.

In-Field Checks

The Installation and Operation sections of your operator's manual cover the adjustments which may be required on your swather. Read these sections carefully before using your swather. Make the necessary adjustments before operating your machine, and check these adjustments periodically as required.

Storage

Store the swather on firm ground away from areas of human activity.

If the storage location exposes the swather to road salt during the winter months, thoroughly wash the swather in spring time.

It is recommended to rotate the drapers so that the seam of the join is located underneath the table. This will improve drainage.



Safety Decal Locations

The following safety decals have been placed on your machine in the areas indicated. They are intended for your safety, and the safety of those working with you. Please take this manual, walk around your machine and familiarize yourself with the locations and content of these warning signs and labels. Review this information, and the operating instructions in this manual with your machine operators. Keep decals legible. If they are not, we suggest you obtain replacements from your Honey Bee dealer.

- 1. Keep them clean, and...
- 2. Know the location and meaning of all decals. Cross reference the numbers on the diagram below with the chart on the following pages to help identify the labels.

For continued safe operation of this machinery, it is recommended that you replace damaged safety decals immediately. You may purchase replacement decals from your dealer.

The following diagram (See Figure 3: Safety Label Locations), indicates the location of all labels on your swather. Match the number indicated in this diagram to the numbered illustrations provided.





Safety-Related Decals

Vehicle Marking Reflectors: (not shown on illustration)

- Red (2x9) 6 Locations
- Yellow (2x9) 3 Locations
- Red-Orange (2x9) 4 Locations



WARNING



In case of hydraulic system failure, reel may drop quickly. Engage safety latch before working under reel. Failure to comply could result in death or serious injury.



A DANGER

WARNING

Install cylinder locks before working on or under raised reels.

Rotating part hazard

To prevent serious injury or death from rotating parts:

1. Keep hands, feet, hair and clothing away from moving part.



5

1

3

DANGER

Knife sections are sharp

1. Wear heavy canvas or leather gloves when working with knife.

2. Be sure no one is near the cutter bar when removing or rotating knife.

Honey Bee Manufacturing Ltd.

John Deere 4990-4995 WS Swather – Operator's Manual

6





This Page Is Intentionally Left Blank



Installation Instructions

This information is designed for first-time installation, but will be valuable every time you are re-mounting the swather to the windrower. It is suggested that you follow the instructions in the order that they are given to avoid difficulties. Use the check lists at the end of this section to ensure that the swather is mounted properly and ready for the field.

Mounting and Dismounting Terminology

Power Unit:	FRONT BACK OR REAR RIGHT and LEFT	Lift arm end of the windrower. Engine end of the windrower. As seen when sitting in the driver's seat facing the
		swather.
Swather Table:	FRONT BACK OR INSIDE RIGHT and LEFT	Cutter bar side Lift arm mount side. As seen when sitting in the driver's seat facing the swather when it is mounted on the windrower.



Illustration 1: General Information - Directions



4990-4995 Swather Mounting Kit



Illustration 2: Swather Adapter Kit Components

Please read these instructions carefully, noting the configuration details that are applicable to your windrower.



Preliminary Information

IMPORTANT!

Please study the information listed on the following page prior to starting any work on either the windrower or the table to determine whether the windrower lift-arm cylinders require changes. If changes are required, completing them at this point will result in savings of dealer time in equipment setup.

If your table setup requires that the lift arm float cylinders be swapped, proceed to <u>LEVELING</u> <u>Option 2 - Switch the Lift Arm Cylinders (</u>located in the Leveling chapter of this manual). After completion of the cylinder switch, return, and proceed from this point in the manual. If you determine that your table does NOT require the lift arm float cylinders to be switched around, proceed from this point.

JD Windrower Float Cylinder Recommendation with Honey Bee

0	5					
	No Hitch	Hitch	Float Pressure			
18'	Swap Cylinders	No Change	Approximately 1200 psi at cutting height			
21'	Swap Cylinders	No Change	Approximately 1250 psi at cutting height			
25'	Swap Cylinders	No Change	Approximately 1500 psi at cutting height			
30'	Swap Cylinders	No Change	Approximately 1700 psi at cutting height			
*36'	Swap Cylinders	No Change	Approximately 1900 psi at cutting height			

Single Knife / Double Knife - Single Swath

Single Knife / Double Knife - Double Swath

	No Hitch	Hitch	Float Pressure
18'	N/A	N/A	N/A
21'	Swap Cylinders	No Change	Approximately 1250 psi at cutting height
25'	Swap Cylinders	No Change	Approximately 1500 psi at cutting height
30'	Swap Cylinders	No Change	Approximately 1700 psi at cutting height
*36'	Swap Cylinders	No Change	Approximately 1900 psi at cutting height

***NOTE:** For 36' Double knife with hitch, floatation may be improved by replacing the 2 3/4" cylinder with another 3" cylinder with 1900 psi float pressure.



Power Unit Preparation

Hydraulic Modifications - JD 4990 / 4995

Remove any attachments from the windrower as outlined in your John Deere Owner's / Operator's manual.

Mark the hoses before you remove them, so you can re-connect them correctly later.

Installing Quick Couplers

Install quick couplers and fittings of the sizes shown, as indicated below:



Illustration 3: Quick Coupler Fittings - detail

NOTE: Use thread sealant only on fittings with PIPE thread. DO NOT use thread sealant on fittings that have an "O" ring, face seal, or JIC swivel.

Honey Bee Manufacturing Ltd.



John Deere 4990-4995 WS Swather – Operator's Manual

The John Deere hydraulic motor is not used with the Honey Bee swather. If you own an auger platform, the motor, with the newly installed quick couplers, can be stored on the platform. Otherwise store the motor in a clean, safe, and convenient location for future use.

- 1. On the motor, remove the 3/8" case drain hose from the top. Install a 4MP-8MF nipple (also included in the kit is the alternate fitting 4MP- 8MJ) to the hose. To this fitting, install the dust cap and the 1/4" male quick coupler.
- 2. If the motor has the 8MF-12MB (8MJ-12MB) adaptor, remove it from motor and install the plug fitting (fitting with a hole in the middle) into the motor. Install a 4MP-4MP nipple into previous fitting, and install the dust cap and female quick coupler to the nipple.
- 3. Remove the 16MF-16MB-45° elbows from the motor, and install 16MB-12MJ–45° elbows in their place. Install the 12MB-12FJX swivel adaptors, with dust caps to the 3/4" quick couplers; ensuring you put the male fitting on the forward pressure side and female on the return.
- 4. Thread a 16MF-12MB, dust cap, and 3/4" male quick coupler to the reverse pressure hose.
- 5. Thread a 16MF-12MB, dust plug, and 3/4" female quick coupler to the forward pressure hose.

John Deere 4990-4995 WS Swather – Operator's Manual

Install Tilt Cylinder Quick Couplers



Illustration 4: Tilt Cylinder Couplers

- 6. On the tilt pressure hose, install a 1/4" male quick coupler, dust cap, and a 4MP 4MF nipple (alternate fitting 4MJ 4MP).
- 7. On the return side, install a 1/4" female quick coupler, dust plug, and a 4MP 4MF nipple (alternate fitting 4MJ 4MP).
- 8. Install a 4MP 6MB 90° elbow to the rod end of the cylinder, and from the elbow, a 1/4" female quick coupler and dust plug.
- 9. Install to the cylinder end a 4MP 6MB 90° elbow, a 1/4" male quick coupler and dust cap.

NOTE: The reel lift is controlled by the platform tilt circuit on the power unit. The hose connected to the front port of the tilt cylinder will be the reel lift pressure hose. The hose from the power unit must have a male quick coupler.

If the reel lift does not work check that the hoses are connected properly, and the couplers are fully engaged.

Honey Bee Manufacturing Ltd.



John Deere 4990-4995 WS Swather – Operator's Manual

Install the Windshield Guard

The windshield guard is designed to prevent the top link rising above the designated limit and destroying the glass.

 Install the guard by securing the 1 inch hitch pin through the right side holes and the power unit top link mount. Clamp the guard in place using the clamp plate and ½ x 2-1/2 in bolts, lock washers, and nuts.

A chain is located on the side of the guard to secure the top link to the guard when the table is not connected to the power unit and a quick disconnect is required.

2. Attach the chain using a 5/16 x 1" bolt, two flat washers, and a c/lock nut.

An extra hole is located on the guard to relocate the existing wire clip to the guard, keeping the electrical lines in order.

3. Attach the clamp using a 3/8 x 1-1/4" bolt, lock washer, and nut.



Illustration 5: Windshield Guard



Illustration 6: Wire Clip



Install the Manual Lift Link (Standard Equipment)

Install the manual lift link using the following diagram for reference:



Illustration 7: Manual Lift Link - Exploded View

Install the Hydraulic Tilt Cylinder (Optional Equipment)

Refer to the table on the following page for descriptions of the numbered items below:



Illustration 8: Hydraulic Tilt Cylinder - Exploded View

- 1. Connect port #1 to hose #24 using a #12 fitting.
- 2. Connect port #2 to fitting #11 and coupler # 17.
- Connect port #3 to fitting #12 and hose # 23.



Illustration 9: Hydraulic Tilt Valve Assembly

Honey Bee Manufacturing Ltd.



	Item #	Quantity	Description
1		2	Bolt – 5/16 x 2-1/4" UNC
2		1	Bolt – 3/4 x 4-1/2" UNC
3		1	Nut - 3/4 UNC
4		2	Nut 5/16 UNC Flange Lock
5		4	Washer, flat 5/16 plated
6		1	Washer, lock 3/4 plated
7		1	Elbow 6MB-6MJ – 90°
8		1	Elbow, swivel 6MJ-6FJX – 90°
9		1	Nipple, 6MB-6MJ
10		1	Nipple, 4MP-6MJ
11		1	Nipple, 4MP-8MB
12		2	Elbow, 6MJ-8MB – 90°
13		1	Nipple, 4MP-6MB
14		1	Adaptor, swivel, 4MP-6FJX
15		1	Bushing, RB-58
16		2	Quick Coupler, 1/4 Male PKR
17		2	Quick Coupler, 1/4 Female PKR
18		1	Hirschmann – Gasket
19		1	Hirschmann – Screw
20		2	Quick Coupler, 1/4 Male Dust Cap
21		2	Quick Coupler, 1/4 Female Dust Cap NH
22		1	Valve Assembly – Hydraulic Header Tilt
23		1	HH04 66 6FJX-6FJX
24		1	HH04 13 6FJX-6FJX
25		1	Lift-link bracket - Slotted
26		1	Cylinder 2 x 8"
27		1	Bushing, Lift-link Cylinder
28		1	In Cab Switch
30		1	Hitch Pin
31		1	Lift-link Sleeve
32		6	Washer, flat 1" plated



 Attach the lift link bracket as shown for the 4990/4995 Windrower, using the items and fasteners shown in Hydraulic Tilt Cylinder - Exploded View, page 31.



Illustration 10: 4990-4995 Lift Link Bracket

2. Attach the 2 x 8" Cylinder by inserting the bushing into the end of the cylinder. Insert this end of the cylinder into the lift-link bracket and secure with the bolt, nut and lock-washer. Refer to Hydraulic Tilt Cylinder - Exploded View, page 31 for details and orientation of the components.

The Installed cylinder, in storage position, should appear as shown below:



Illustration 11: Hydraulic Tilt Cylinder - Storage Position

Honey Bee Manufacturing Ltd.

John Deere 4990-4

John Deere 4990-4995 WS Swather – Operator's Manual

- 3. Refer to Wiring Bracket Exploded View, below. Install the bracket mount to the power unit using the hardware shown. Connect the quick coupler valve under the bracket using the 5/16 u-bolt, 1/4 quick coupler dust cap, 5/16 and 3/8 fender washer, and c/lock nuts.
- 4. If the hydraulic tilt cylinder option (previous page) has been ordered, install the valve assembly to the mount using the hardware supplied. The Hirschmann plug should also be installed at this time using the gasket and screw provided.



Illustration 12: Wiring Bracket - Exploded View

NOTE: This diagram shows the hydraulic connections for the manual link, see Illustration 8: Hydraulic Tilt Cylinder - Exploded View, page 31 for hydraulic tilt connection.
Honey Bee Manufacturing Ltd.

Honey Bee

John Deere 4990-4995 WS Swather – Operator's Manual

- 5. On the tilt pressure hose, install a ¹/₄ inch female quick coupler and dust cap. Install a 4MP 8 MB nipple to the valve Assembly "2" port.
- 6. On the return hose, install a 1/4" male quick coupler and dust cap. Install a 4MP 6MB nipple to the tilt cylinder (cylinder end).
- From the Rod end of the cylinder, install a 66 inch 6FJX 6FJX hose with a 6MB 6MJ nipple. On the other end of the hose install a ¼ inch female quick coupler with a 4MP – 6MJ nipple plus dust plug.
- 8. From the valve assembly "3" port, connect a 6MJ 8MB 90° elbow to a 6MJ 6FJX 90° elbow, to a 4MP 6FJX adaptor, to a ¼ inch male quick coupler and dust plug. This assembly will then be connected to the 66 inch hose assembly.
- From the "1" port of the valve assembly, install a 6MJ 8MB 90° elbow to a 13 inch 6FJX 6 FJX hose, to a 6MB 6MJ 90° elbow, which is then connected to the quick coupler lever.



Illustration 13: Bracket Installation Complete

Honey Bee Manufacturing Ltd. John Deere 4990-4995 WS Swather – Operator's Manual

Installing the Needle Valve

Refer to the illustrations on the next two pages to familiarize yourself with the locations of the components involved.

1. On the left side of the power unit at the top of the stairs, access the compartment door behind the cab.

At the top-front of the compartment, you will find small nuts and bolts that will line up with the bracket shown at right.

- 2. Loosen the nuts from the two locations identified. Remove the nut and bolt from the top location but DO NOT REMOVE THE NUT from the side location (since the bolt may fall out making reinstallation difficult).
- 3. Slide the bracket between the previously loosened nut and frame. Insert a 5/16 bolt (included) through the top hole of the frame. Thread the washer and nut onto the top bolt. Tighten the nuts to secure.



Illustration 14: Needle Valve Mounting Bracket



Illustration 15: Needle-Valve bracket in position

Honey Bee Manufacturing Ltd.



John Deere 4990-4995 WS Swather – Operator's Manual

4. To locate the manual float release valve, open the side panel on the left side of the power unit at the top of the stairs (see bracket installation) and relieve the pressure by opening the valve (counter clockwise).



Ensure that you open the valve prior to disconnecting any hoses to avoid excess spillage or potential harm from pressurized oil.



Illustration 16: Needle Valve and Hydraulic Control Block

The following sequence will minimize oil spillage.

 Disassemble the needle valve knob from the body and reassemble using the panel nut and washer as shown. Install the supplied hose "B."

Units with serial numbers starting at 320001 and up will use the needle valve assembly shown in the illustration to the right.



Illustration 17: Needle Valve - Exploded View

NOTE: Units with serial numbers up to and including 320000 will require the threaded hose fittings also included in the installation kit. Units from serial number 320001 and up will use the non threaded "STC" fittings.

Honey Bee Manufacturing Ltd.



John Deere 4990-4995 WS Swather – Operator's Manual

Units with serial numbers up to and including 320000 will use the needle valve assembly shown here.



Illustration 18: Needle Valve - Non-STC Threaded Fittings

 Disconnect the platform lift hose "A" at the block, using the valve tool provided in the compartment. Connect the supplied hose "B" as seen in Illustration 16: Needle Valve and Hydraulic Control Block, page 37. Now connect Hose A to the needle valve, as shown in the same illustration.

7. Slide the needle valve onto the mounting bracket, as shown in Needle-Valve bracket in position, page 36, and secure in place with the panel nut. Close the manual float release valve on the block (clockwise) and set a small flow rate on the needle valve (counterclockwise.)



Illustration 19: Hydraulic Control Block



Illustration 20: Needle Valve



Honey Bee Manufacturing Ltd. John Deere 4990-4995 WS Swather – Operator's Manual

Wiring Installation

Model Identification

It is important that you determine exactly which model of windrower you have. Possible variations are:

New Models

All John Deere 4995 units built after The cab will have the correct in-cab wiring and switch panel factory installed. *No in-cab modification is* including, and after: E04995X330675. *required!*

Draper Option

If the power unit was ordered specifically for use with a Honey Bee draper platform (*Honey Bee Ready*,) all switches for this option will be installed in the panel. *If the unit was not ordered with this option*, the switches will be supplied by Honey Bee, and will need to be installed and plugged into the existing harness by the dealer.

If you have identified your unit as a "New Model," proceed to New Model Wiring, page 40.

Older production modelsProceed as instructed in Wiring Installation – Older
Models, page 43. Switches and in-cab harness will
be supplied by Honey Bee.

Honey Bee Manufacturing Ltd. John Deere 4990-4995 WS Swather – Operator's Manual

New Model Wiring

- 1. Identify the 21-pin plug of the wiring adapter, and mount this end in the front bracket of the windrower, located on the right hand side of the cab.
- 2. Feed the other end of the harness under the cab.



Illustration 21: Bracket



Illustration 22: Wiring Harness Clip



Illustration 23: Access to Rear Electrical Panel

You will find a wiring harness clip under the cab floor.

3. Feed the wire into this clip and secure it with a zip-tie.

Toward the rear of the cab, you will see an opening in the frame.

4. Feed the 31-pin plug through to the exterior via this access.

Honey Bee Manufacturing Ltd. John Deere 4990-4995 WS Swather – Operator's Manual

 Insert the 31-pin plug into the receptacle provided. The plug will align in the same fashion as the front plug, by first aligning the widest tab in the plug with the wide slot in the receptacle. Once it is fully seated, turn the locking collar to secure the plug.





Illustration 25: Plug Location

Illustration 24: 31-pin Plug

 If the unit was not ordered "Honey Bee Ready," remove the screws holding the switch panel in place, and remove the approriate switch position blank(s). Snap the new switches in place, as shown here, and connect them to the harness plugs as shown in the windrower manual.



Illustration 26: 4995 Switch Panel

John Deere 4990-4

Honey Bee Manufacturing Ltd. John Deere 4990-4995 WS Swather – Operator's Manual

 Open the electical panel access on the right side of the windrower. Remove the float relay from the electrical panel. With this relay removed, the table will raise and lower only so long as the switch is activated, and will stop when it is released.

For the successful completion of this installation, the relay should be removed; however, if you prefer, it may be replaced for field use. With the relay in place, the table will lift to maximum height when up is selected, and will lower to the preset float height when down is selected.



Illustration 27: Electrical Panel - Float Relay

NOTE:

When hooking up to the swather, this relay should be removed to provide fine control over the operation of the hydraulics.



Wiring Installation, Older Models

4990 Model Switch Installation

Switches for the standard draper speed control, optional deck shift and reel fore/aft option are supplied for installation into an addon, prewired control panel. This panel is installed using the two screws that secure the cup holder.

 Remove the cup holder, place the bracket for the panel, aligning the holes, place the cup holder bracket over this, and replace the screws.



Illustration 28: 4990 Switch Panel

4995 Model Switch Installation

Reel speed and table tilt /reel lift operations are controlled with the standard switches located on the F-N-R control lever.

The switches for the standard draper speed control, optional shifting decks, fore/aft reel options, and the table tilt/reel lift options need to be installed in the control console. If additional switches are required, refer to Illustration 29: 4995 - Suggested Switch Locations page 44 for switch locations.

Honey Bee Manufacturing Ltd. John Deere 4990-4995 WS Swather – Operator's Manual

 Remove the three screws holding the console panel cover, lift the cover, mark, and unplug the cables to the switches.



Illustration 29: 4995 - Suggested Switch Locations

- 2. Locate the knockout(s) for the options to be installed, using the suggested sequence shown.
- 3. With a sharp knife, cut the vinyl cover along the edge of the knockout.
- 4. Cut the metal tabs at each end of the opening and file any burrs smooth.
- 5. Insert the new function switch or switches from the top and snap into place.



Illustration 30: Suggested Switch Placement

Honey Bee Manufacturing Ltd. John Deere 4990-4995 WS Swather – Operator's Manual

If only one option is added, no modification to the control console base is required; however, with two, or more options, the modifications shown to the right are needed.

- 6. Feed the new harness up, inserting the appropriate plugs through the holes so they will line up with the switches in the panel.
- 7. Connect the plugs to the corresponding switches, and replace the panel cover using the three screws removed earlier.



Illustration 31: Console Modification

The template (Illustration 32: Console Cutting Template, page 45), will give you the correct sizes for the openings shown above.



Illustration 32: Console Cutting Template

Honey Bee Manufacturing Ltd. John Deere 4990-4995 WS Swather – Operator's Manual

4990 and 4995 Models – Cab Modifications

 A hole must be made in the floor for the wiring loom supplied for these options. Raise the floormat and locate a small plate welded to the floor.

The hole diameter should be at least 2-1/2" to allow the prewired plug and wiring loom to be fed through the floor.

(See the photos to the right and below.)

9. Install the wiring harness and reclose the hole with the grommet and plate supplied. Secure with four (4) sheetmetal screws.



Illustration 33: Hole Location



Illustration 34: Wiring Installation Complete



Illustration 35: Hole Location - Closeup View

- 10. Open the electrical access panel on the right-hand side of the windrower. Remove the float relay from the panel on the door.
- 11. If the optional deck shift, draper speed (now standard), fore and aft, and/or hydraulic tilt was purchased, connect the plug from the newly installed console wiring into the optional power source plug.

Honey Bee Manufacturing Ltd. John Deere 4990-4995 WS Swather – Operator's Manual



Illustration 36: Wiring Panel Access

NOTE: The swather may be operated with the float relay left in place. In this case, when the "Up" switch is activated, the table will rise to the the top of its travel. Similarly, when the "Down" switch is activated, the table will lower to the preset float height.
When hooking up to the swather, this relay should be removed to provide fine control over the operation of the hydraulics.
If you wish, it may be re-installed once these setup instructions have been completed.



Install Lift-Arm Extensions

 Place the lift arm extensions on the power unit lift arms. Secure the extension to the lift arm by installing the clamp plate under the lift arm using ³/₄ x 7 inch bolts and nuts.

Tighten the bolt only until 2 or 3 threads are exposed past the top of the nut.

 Secure the lift arm extension in place using the M24 17cm x 2.4cm bolt and the M24 nut provided.

Do not overtighten the 3/4 x7" bolts. These extensions are designed to act as a hinge between the windrower lift arms and the table.



Illustration 37: Lift Arm Extension



Illustration 38: Lift Arm Assembly Complete



John Deere 4990-4995 WS Swather – Operator's Manual

Swather Preparation

Crop Divider Installation

- 1. Park the Grain Belt Swather on flat, hard, and level ground. support the hitch end of the unit by extending the hitch jack until the swather is sitting level.
- Install the crop dividers, and crop divider pipes to the ends of the table. The crop divider and pipes are not installed at the factory for shipping purposes. Once installed, operators should be aware of the assembled width of the swather, and should check local regulations before transporting on public roadways.
- 3. The crop divider is held in place with six (6) 3/8 x 1-1/4" carriage-head bolts. Three bolts are installed through the base of the divider, and the table shoes at each end of the table. They are held in place using the supplied flat washers and lock-crimp nuts. All holes are pre-drilled.

When properly positioned, the crop divider overlaps the outside of the crop deflector to provide a smooth transition for the crop. The remaining three carriage-head bolts are installed from the inside of the formed sheet metal portion of the crop divider, into the crop deflector using flat washers and crimp-lock nuts.



Illustration 39: Crop Divider- Exploded View

4. Insert the crop divider pipe into the nose of the crop divider and insert a 3/8 x 2" carriage-head bolt. With the bolt in place, place a bushing-spacer followed by a flat washer, and tighten with a lock nut. The bushing should press firmly against the crop divider pipe to hold it firmly in place.

Honey Bee Manufacturing Ltd. John Deere 4990-4995 WS Swather – Operator's Manual

NOTE: The inside edge of the crop divider and pipe should be aligned so that they are approximately 90 degrees (right angle) to the cutter bar. This will provide good crop separation, and will help prevent crop plugging in the corners.



Illustration 40: Crop Divider Complete

Draper Installation

Please refer to the Draper chapter in this manual.

Honey Bee Manufacturing Ltd. John Deere 4990-4995 WS Swather – Operator's Manual

Installing the Strut Rollers

The JD 4990 and 4995 swather comes with two standard rollers from factory. One of these rollers needs to be replaced with a base plate roller.

1. Remove the 5/8" hitch pins.

The hitch pins will be used later to secure the lift arms.

- 2. Remove both rollers. The roller from the right hand strut will be moved from the left side opening to the right side opening. The roller from the left hand strut will be replaced.
- Connect the base plate roller to the left hand strut using the 1"x10" UNC bolt, 3/4"x1 1/2" UNC bolt, as well as the washers and nuts provided.
- 4. Connect the standard roller to the right side opening of the right hand strut as shown in the illustration to the right.



Illustration 41: Installation of Strut Rollers



Illustration 42: Securing the Base Plate Roller.

Honey Bee Manufacturing Ltd. John Deere 4990-4995 WS Swather – Operator's Manual

Install the Hose Holder

A bracket and canvas loop are provided to route the hydraulic hoses both while in use, and in storage. Use of this hanger will prevent damage to the hoses and connections from being run over, or trailed on the ground.



Illustration 43: Hose Connected to Swather



Illustration 44: Hose Hanger - Close-up View



Illustration 45: Hose in Storage Position

Honey Bee Manufacturing Ltd. John Deere 4990-4995 WS Swather – Operator's Manual

Mounting the Swather to the Windrower

 Park the swather and transport unit on firm, level ground, where it will be easily accessible for the windrower operator to pick up.



Illustration 46: Swather on Transport Unit

2. Lower the screw jack, located on the side of the transport axle, and raise the axle until the tire clears the ground.

Remove the quick pin securing the hub and spindle, and remove the wheel assembly. Store the wheel assembly in an appropriate location, or if the gauge wheel option has been purchased, install the wheel into the left-hand gauge wheel mount and secure with the quick pin as seen below.





Illustration 47: Wheel Assembly Removed

3. Start the windrower. Test the lift-arm controls to ensure smooth operation.

Honey Bee Manufacturing Ltd.

John Deere 4990-4995 WS Swather – Operator's Manual

NOTE: If the lift arms move too abruptly, reduce the flow of oil at the needle valve as shown in Illustration 20: Needle Valve, page 38.

If they raise and lower fully with one cycle of the control, ensure the relay shown in Electrical Panel - Float Relay, page 42, and 47 has been removed.

4. Move the windrower into position, lining up the lift arm extensions with the outside channels of the struts on the swather. Ensure the arms are low enough to move under the struts.



Illustration 48: Positioning the Windrower



Illustration 49: Lifting the Extension Arm

5. Slowly raise the lift arms until they are firmly set on the rollers. Ensure the end of the extension arm has fully engaged the roller.



Illustration 50: Left Roller Engaged





6. If the arms are located correctly, insert the Hitch Pins and secure.



Illustration 52: Left Roller Pin Installation top view.



Illustration 53: Right Roller Pin Installation bottom view.

Warning! Do not attempt to lift the swather until safety chain is attached!

 Connect the safety chain to the windshield guard, and the swather as shown. The chain is supplied with a bolt through one of the links to mark the minumum length of chain. *Do not remove this bolt.*

Attach the manual, or hydraulic top link, as shown to the right, and Illustration 55: Manual Lift Link, page 56.

Ensure you insert the collar into the swather-end of the link before sliding it in place in the tower. Insert the hitch pin in the lower hole of the bracket tower and secure it as shown.



Illustration 54: Safety Chain & Hydraulic Tilt

Honey Bee Manufacturing Ltd. John Deere 4990-4995 WS Swather – Operator's Manual

8. If lining up the link is difficult, carefully raise the swather small amounts until it lines up.

This step should not be required if the hydraulic tilt option is used.

- 9 Observe the positioning of the manual link to the right. You will note this is mounted in the identical locations as used for the hydraulic link shown in Illustration 54: Safety Chain & Hydraulic Tilt page 55.
- 10. Carefully raise the swather to full height, then lock the arms, using the windrower's lock lever.



Illustration 55: Manual Lift Link



Illustration 56: Windrower Table Lock



Illustration 57: Securing the Tilt Cylinder

11. If using the Hydraulic Tilt Option, secure the hydraulic tilt cylinder in place using the hitch pin provided. Ensure that the hitch pin is inserted from below as shown in illustration Illustration 57: Securing the Tilt Cylinder



Honey Bee Manufacturing Ltd. John Deere 4990-4995 WS Swather – Operator's Manual

12. Remove the wheel assembly from the cutter-bar side of the table, and store in an appropriate location, or install onto the right-hand gauge wheel, if this option was purchased.

Remove the pin holding the axle extension in place and slide the axle into the housing.



Illustration 58: Axle Tube Retraction

13. Secure the axle in the housing by reinserting the pin in the rear hole.



Illustration 59: Axle Tube Retracted

John Deere 4990-4995 WS Swather – Operator's Manual

Honey Bee Manufacturing Ltd.

14. Remove the jack and remove the pin holding the axle strut in the vertical position.



Illustration 60: Axle in road Position

15. Swing the axle up, and secure using the pin. Replace the jack as shown and secure with the pin.





Illustration 61: Axle in Field Position

1. Connect the electrical lines, and the hydraulic reel lift/tilt hose (standard on

NOTE: The optional hydraulic swather tilt connection is also shown here (top right). Connect this now if you have not already done so.

2. Open the valve to the reel lift/tilt cylinder (curved arrow).



NOTE: If you need to refer to hydraulic schematics, see the Hydraulics Schematics chapter.

NOTE 2: When the swather is being stored, the case drain hose should be left connected to relieve pressure in the closed hydraulic system, thus avoiding potential damage to system components.

John Deere 4990-4995 WS Swather – Operator's Manual

Connect Electrical and Hydraulic Systems

- all tables) at the plug mount, located on the right-hand side of the cab.
 - Illustration 62: Windrower-Swather Connections

Pressure Return Illustration 63: Main Hydraulic Connections





Honey Bee Manufacturing Ltd.

Honey Bee

Honey Bee Manufacturing Ltd. John Deere 4990-4995 WS Swather – Operator's Manual

Store the Transport Hitch

The swather should be lifted from the ground at this point, with the table safety lock in place.

1. Fully retract the jack leg, by raising the screw-driven section, and by collapsing the lower section (foot) to the first hole.



Illustration 64: Hitch Components

2. Release the hitch clamp, and slide the jack off the hitch tube. Store the jack as shown below, and tighten the clamp.



Illustration 65: Jack In Stored Position



Illustration 66: Removing the Jack

3. Pull the lock pin on the hitch tube and slide the tube into the storage sleeve. Refer to Illustration 64: Hitch Components. Attach the hitch safety chain to the storage stub as shown above.

If excessive vibration occurs, extend the jack until it contacts the hitch tube storage sleeve, as shown above.





John Deere 4990-4995 WS Swather – Operator's Manual

Leveling the Swather

If the table requires leveling at this stage, you have three options, which you may elect to use singly or in any combination. These three options can be found in the Leveling chapter of this manual.

Programming the Tachometer

It is not necessary to start the engine to program the tachometer. These instructions apply to either single or dual display tachometers.

- 1. Move the key to the "OFF" position.
- Press, and hold the Ground Speed (C) and Float Pressure (F) buttons while turning the key to the "RUN" position.
- 3. This will open the setup mode.
- The "Function Selected" display (A) should highlight the upper left quadrant, and the primary machine code will be displayed in (H)
- Press the Ground Speed (C) or Engine Speed (D) button to incrementally adjust the code up or down until it reads "13."
- Press Reel Speed (E) and Float Pressure (F) buttons simultaneously to store the code and move to the next step.
- 7. The upper right quadrant will now be highlighted in the "Function Selected" display (A).
- Press the Ground Speed (C) or Engine Speed (D) buttons incrementally, until this display reads "0" for the 4990, or "1" for a 4995 which provides greater input range for reel speed and platform speed.



Illustration 67: Tachometer

- A Function Selected
- **B** Engine Hours
- C Ground Speed (mph)
- D Engine Speed (rpm)
- E Reel Speed (knife drive)
- F Float Pressure (psi)
- G Platform Hours
- H Digital Display

Honey Bee Manufacturing Ltd.

Honey Bee

John Deere 4990-4995 WS Swather – Operator's Manual

NOTE: If the display does not read correctly with Code "1", try Code "0" as an alternate.

- 9. Press the Reel Speed (E) and Float Pressure (F) buttons simultaneously to store the code and move to the next step.
- 10. The Function Selected display (A) will now have the lower right quadrant highlighted. Press the Ground Speed (C) or the Engine Speed (D) button incrementally to adjust this reading to *"26" for units prior to the 2002 model year.* Beginning with the 2002 model year, this number will be *"24.5"* to reflect the change in final drive ratios.
- 11. Press the Reel Speed (E) and Float Pressure (F) buttons simultaneously to store this code and move to the next step. The Function Selected display (A) will now have the lower left quadrant highlighted. The number of pulses per engine revolution will be shown on the digital display (H).
- 12. Press the Ground Speed (C) or the Engine Speed (D) button incrementally until the display reads "30".
- 13. Press the Reel Speed (E) and Float Pressure (F) buttons simultaneously to store this code.
- 14. Turn the key to the "OFF" position to exit the setup mode.

Calibrate the Hydraulic Pump

Honey Bee

JD 4990-4995 Install the Flow-control Bracket

Set the engine high idle to 2100 RPM. Normal pump output is 45 gpm (170 lpm). The Honey Bee swather requires a flow rate of **19.5 gpm (88.5 lpm)**. Install the flow bracket assembly onto the motor mount, located under the windrower, as shown below.



Illustration 68: Pump Adjuster Mounting Bracket



Illustration 69: Pump Adjuster Assembly Complete

- 1. Remove the nuts from the two bolts holding the electric header pump output controller. Place the bracket on these bolts as shown above, replace, and tighten the nuts.
- 2. Remove the cotter key holding the linkage lever onto the electric controller. **Do not** *permit the linkage rod to turn in the clevis end of the linkage, to avoid calibration problems when the rod is returned to the electric controller arm for other applications.*
- 3. Relocate the linkage into the adjusting bolt attached to the bracket you installed previously. Secure by replacing the top washer and use a new cotter key to secure the linkage in place.
- 4. Start the engine and set high idle (2100 rpm). Select the Reel Speed display, which shows the knife speed on the tachometer. (See your windrower operator's manual.)
- Adjust the length of the linkage from the bracket until the readout shows 700 rpm. Secure the lock nut. Recheck the knife speed to ensure it has not changed. You may verify this setting by installing a flow-meter to the output and return hoses, (19.5 gpm 88.5 lpm), or by using a photo-electric tachometer on the knife drive, in which case, the reading should also be 700 rpm.



Honey Bee Manufacturing Ltd.

John Deere 4990-4995 WS Swather – Operator's Manual



Exceeding speeds of 700rpm may cause damage to knife, knife drive or knife heads and void your warranty.

Mounting Checklist

Lift arm assemblies fitted to the lift arms of the windrower.
Lift arm and top link pins, bolts, and fasteners in place and secure.
Transport axle and hitch tube in the storage (field) position.
Transport parts stored for future use.
Gauge wheels installed and secured. (if equipped.)
Hydraulic lines (quick couplers) connected.
Reel lift hose connected to the tilt circuit.
Electrical connections complete and tested.
Float relay removed.
Reel tie down strap removed.
Swather table leveled.



John Deere 4990-4995 WS Swather – Operator's Manual

System Tests

Once all installations have been completed, the entire system should be tested to ensure everything is operating correctly. If a fault is detected, troubleshoot, and correct as needed.

NOTE: If possible, the following tests should be completed with an observer present at a safe location outside, with a clear line of sight to the operator. If this is not possible, complete the tests with the cab door open, so the operator can more easily detect unusual noises.

Hydraulics, Electrics, and Mechanical

1.	Check all fluid levels and top up if needed.
2.	Start the windrower, run the engine at low idle. Raise and lower the swather and adjust the needle valve to achieve a suitable rate of movement, given the present engine speed. Advance engine RPM to normal operating range, test the rate again, and adjust as necessary.
3.	Return the engine to idle RPM. Engage each of the swather controls, one by one, to test the electrical and hydraulic connections. Select the applicable function on the tachometer for each system you activate, and monitor its readings to ensure they are accurate.
4.	Engage all systems, and slowly advance throttle to normal operating RPM. Check that all systems are running at normal speed with no signs of problems or interference.
5.	Stop all systems, turn the engine off. Inspect the swather to ensure everything is secure, and there are no signs of abnormal operating conditions. Make adjustments as required, and re-test as necessary.
6.	Check hydraulic fluid levels and top up if necessary.

Control Console Wiring Schematics

JD 4895-4995 WS Swather – New Wiring Configuration



Illustration 70: New JD 4895/4995 Wiring Schematic

Applicable to all JD 4995 units with serial numbers including and after E04995X330675 and all JD 4895 units with serial numbers including and after E04895X330107.

John Deere 4990-4995 WS Swather – Operator's Manual

$(\mathbf{P}, \mathbf{4}, \mathbf{0}, \mathbf{0}, \mathbf{0})$ NOTE: All wires to switch connectors g through a 4" piece of SW 1" shrink tube at drop. HoneyBee Manufacturing Ltd. DAL 01/17/07 Canvas Speed ц., U Drop 2" 1-3/4" SW : 0 (\mathbf{r}) (m) (m) (m) 6 rellow P 9 0 0 0 Deck (m) \$ 4 11" PANEL WIRING SCHEMATIC - JD 4895/4995 WS SWATHER Hirschm 2 Drop 1" $(\mathbf{P}, \mathbf{d}, \mathbf{d}) = (\mathbf{P}, \mathbf{d}, \mathbf{d})$ (0) 2 Wire Cable White not used. (z Cable But Connects Drop 11 (\mathbf{r}) 1 Pin Female Plug emale Terminals 1.5" O-ring \odot Drop 2" 1-3/4" SW 3/8" shrini < m U (1 \triangleleft All wires (I)

JD 4895-4995 WS Swather – Original Configuration

Illustration 71: Original JD 4895/4995 Wiring Schematic

Applicable to all JD 4995 units with serial numbers before E04995X330675 and all JD 4895 units with serial numbers before E04895X330107.





John Deere 4990-4995 WS Swather – Operator's Manual

JD 4890-4990 WS Swather



Illustration 72: Original JD 4890/4990 Wiring Schematic

Applicable to all JD 4890 and JD 4990 units.



Honey Bee Manufacturing Ltd.

John Deere 4990-4995 WS Swather – Operator's Manual

Operation

Initial Start-up



- Unlock the lift arms by disengaging the platform lock as per windrower Operator Manual's instruction.
- 2. Start the windrower (see operators manual) and lower the swather to the ground.



Engage the parking brake on the windrower, shut the engine down, and wait for all moving parts to stop before leaving the cab.

 With the swather completely lowered, (in full contact with the ground) inspect the swather for damaged or loose parts. Repair or replace any such parts.



Illustration 73: Unlocking the Platform

- 4. Ensure all nuts and bolts are tight and that none are missing. Tighten, and replace as required.
- 5. Check hydraulic reservoir oil level on the windrower. Fill to recommended level according to instructions in windrower owner's manual.
- 6. Ensure that all protective shields are in place and properly secured.
- 7. Check that transport/gauge wheel tires are inflated to the recommended pressure. (50 psi. (345 kPa) for transport, 24 psi. (166 kPa) for field work.)
- 8. Check all hydraulic hoses and fittings to be sure they are tight, properly connected, and that no hose damage has occurred during mounting. Repair or replace any damaged parts before re-starting the machine.

Honey Bee Manufacturing Ltd.

John Deere 4990-4995 WS Swather – Operator's Manual

Do not operate this machinery with defective hoses or fittings.
Ensure hydraulic pressure is released before checking or attempting repairs. Pressurized hydraulics can cause serious injury.

- 9. Lubricate the swather. See service points in the Lubrication section of this manual.
- 10. Restart the windrower (see windrower Operator's Manual). Engage the Park Brake

F-N-R Lever Controls

Locate the platform tilt switch on the F-N-R lever. This switch will be used also as the reel lift/lower control switch. A switch on the console (see the photo) to the right of the lever allows you to select the function of the switch on the F-N-R lever (if equipped with hydraulic tilt option).



Illustration 74: F-N-R Lever Controls

Depress the platform tilt switch to raise the reel to its full height (cylinders fully extended). Hold switch on momentarily, then drop the reel to its lowest position (cylinders fully retracted). Complete this cycle at least twice to ensure the system is working properly.



Illustration 75: Reel Cylinder at Full Extension


Honey Bee Manufacturing Ltd. John Deere 4990-4995 WS Swather – Operator's Manual

Bleeding Air Out Of Reel Lift Circuit

If the reel does not go up or down evenly, it may be necessary to bleed the slave cylinder. Complete this procedure only when the swather drive is disengaged and the swather is resting fully on the ground. Lower the reel to the bottom of the cylinder stroke. The reel cylinders have a center to center collapsed length of 18". Fully extended cylinder length is 28" center to center.

Cycle the reel to the top of the stroke, then lower the reel until about 2" of cylinder rod remains exposed. Shut the windrower down. Wait for 10 to 15 minutes to allow the air bubbles in the oil to dissipate. Loosen the bleed port cap on the slave cylinder (far left hand cylinder). Air and oil will escape, and the reel will settle. Tighten the bleed screw (cap) and cycle the reel again. If needed, repeat this procedure.



Illustration 76: Bleed Port Location

NOTE: Because of expansion in hydraulic lines, it is normal for the left hand slave cylinder to lag slightly when lifting the reel

Single Reel Lift Circuit

When the operator opens the valve in the windrower, oil is forced into the barrel end of the right hand master cylinder (26A), as the cylinder piston rises, oil on the top side of the piston is forced out of the rod end port, into the port on the slave cylinder (28A).



Illustration 77: Single Reel - Lift Circuit



Double Reel Lift Circuit

Pressure from the windrower feeds barrel end of center cylinder (23A). Rod end feeds barrel end of right cylinder (26A). Rod end of right cylinder feeds barrel end of left cylinder (slave) (28A)



Illustration 78: Double Reel - Lift Circuit

36' Single Reel Lift

Pressure from the windrower feeds barrel end of right cylinder (23A). As the cylinder piston rises, oil on the top side of the piston is forced out of the rod end port, into the port on the slave cylinder (27A).

Rod end of slave returns into the table return.



Illustration 79: 36' Single Reel Lift

John Deere 4990-4995 WS Swather – Operator's Manual

Unlock the platform, as shown previously.

Important!	<i>If the windrower will not lift the swather table, see the Trouble Shooting section of this manual.</i>
Warning!	Be certain no one is standing near the machine while you are raising or lowering the swather.

Raise and lower the swather table to ensure the lift cylinders are working properly.

With swather lowered to the ground, and the windrower engine shut down, check the tension on each draper. If adjustments are required, see the *Draper* section of this manual.

Re-start the windrower, engage the parking brake. Engage platform drive switch (see windrower Operator's Manual) with windrower at low idle. The platform draper, knife and reel should begin to turn.

Warning!

If any leaks appear, shut the unit down, and switch off the engine immediately. Locate the source of the leak, and repair before re-starting.

Increase engine speed, until the windrower is at normal operating engine rpm, check and set the following:

- 1. Reel speed.
- 2. Draper speed.
- 3. Draper tracking.

If adjustments are required see the appropriate section of this, or the windrower manual.

Honey Bee Manufacturing Ltd. John Deere 4990-4995 WS Swather – Operator's Manual

With the swather lowered to approximately 2 inches (5 cm) from the ground, stop the windrower, shut the engine down, and check the following:

- 1. Swather leveling (end to end).
- 2. Swather cutting angle.
- 3. Gauge wheel height.
- 4. Reel mount bolts.
- 5. Knife head section bolts and bearing block bolt.
- 6. Knife head bearing bolt.
- 7. Knife drive support/crank bolts.
- 8. Connector bar bolts on knife back.
- 9. Knife drive mounting bolts.

Problems frequently encountered during start-up and break in period

High Hydraulic Pressures - Cold Oil

- 1. Sticky Draper
- 2. Sticky or Tight Knife
- 3. Draper Too Tight

Reel Will Not Raise

- 1. Low Oil Volume from windrower
- 2. Line Restriction
- 3. Valve not open



Honey Bee Manufacturing Ltd.

John Deere 4990-4995 WS Swather – Operator's Manual

Full Dismount



Park the windrower on a hard, level surface. Engage the park brake.

1. With the windrower running, lower the reel to its lowest position. Raise the swather to its fully raised position.



Shut the engine down and wait for all moving parts to stop before leaving the cab. Ensure the park brake is set.

- 2. Lock platform in fully raised position as described previously, and in your windrower Operator's Manual.
- Uncouple all hydraulic hoses connecting swather to the windrower. Tie or lay hydraulic hoses in such fashion that they will not interfere with the windrower or the swather when the windrower is being backed away from the swather.
- 4. Uncouple all wires running from the windrower to the swather (21 pin connector) and store on the dummy connector provided.



Illustration 80: Transport Electrical Connector

Honey Bee Manufacturing Ltd. John Deere 4990-4995 WS Swather – Operator's Manual

Self Storing Hitch – Transport Position

5. To convert the hitch from storage to transport mode, remove the safety chain from the storage stub. Release the pressure on the jack, loosen the locking lever, and slide the jack off of the stub.



Illustration 81: Removing the Jack from Storage

- 6. Pull the lock pin on hitch tube sleeve, and then pull the hitch tube out of the hitch tube sleeve. Reinsert the lock pin to secure the tube.
- 7. Install the jack onto the hitch tube, and tighten the locking lever on the jack mount.
- 8. Extend the lower leg of the jack to a suitable hole.
- 9. Level the swather table using the jack.



Illustration 82: Hitch Tube Extended, Jack Installed

Honey Bee Manufacturing Ltd. John Deere 4990-4995 WS Swather – Operator's Manual

Install Transport Axle

10. Carefully lower the axle from the field position to the transport position. Ensure the hitch pin has been inserted back onto the strut in the transport position.



Illustration 83: Transport Axle Lowered

- 11. Remove the hitch pin securing the extension inside the axle. Pull out the extension and relocate the pin to secure for transport.
- 12. Install the wheel assembly onto the extension on the cutterbar side of the table, insert lock pin into spindle mount and secure with safety clip.



Illustration 84: Axle Extended

Honey Bee Manufacturing Ltd. John Deere 4990-4995 WS Swather – Operator's Manual

- 13. Install the transport axle jack to support the weight at the rear of the table.
- 14. Place the platform lock in the unlock position, as shown previously and in the windrower operator's manual.
- 15. Restart the windrower. Lower the swather until the front transport axle wheel, transport screw jack and hitch tube jack just touch the ground.
- 16. Remove the two hitch pins from the table struts.
- 17. Block transport axle tires so swather will not move once windrower has been removed from swather.
- 18. Release all pressure on the top link, then disconnect the top link.
- 19. If the optional hydraulic tilt cylinder is used, you may remove the hitch pin, then disconnect it from the swather, and place the cylinder in it's storage position, as shown on illustration 11 on page 33. Once secured, you may replace the hitch pin.







Illustration 86: Removing the Hitch Pins

Honey Bee Manufacturing Ltd.

Honey Bee

John Deere 4990-4995 WS Swather – Operator's Manual

- 20. Store the top link (or hydraulic lift cylinder if equipped) against the windshield guard and secure with the light chain.
- 21. Disconnect the safety chain.
- 22. Carefully lower the swather so that the weight is fully on the front wheel, hitch and rear axle jack.
- 23. Continue to lower the lift arms. Once the lift arms are clear of the rollers inside the swather struts, slowly back away.



Illustration 88: Storing the Lift Link

Caution! If the swather moves, stop immediately and find the cause.



Once clear of the swather platform:

- 24. Attach the rear wheel and secure with the hitch pin.
- 25. Lower the jack, remove it and re-install it in the storage position.
- 26. Check that the swather is level. If necessary adjust the height of the hitch jack.



Illustration 89: Axle Ready for Transport



Honey Bee Manufacturing Ltd. John Deere 4990-4995 WS Swather – Operator's Manual

This Page Is Intentionally Left Blank



Honey Bee Manufacturing Ltd. John Deere 4990-4995 WS Swather – Operator's Manual

Reel

REEL POSITION

The reel should be located directly above or slightly ahead of the knife to move the crop material to the drapers and sweep the cutter bar clean. To adjust the reel, use the following procedures:



Clear the area of bystanders and small children before making any of the following adjustments to the swather.

Lower the reel to its lowest position.

STOP

Engage parking brake on the windrower, shut the engine down and wait for all moving parts to stop before leaving the cab.

Measure the amount the reel needs to be moved, either fore, aft, up, or down.

Fore/Aft Adjustment (Manual Version)

Pull the lock pins in both reel mount brackets until the pins are clear of the lock hole. Tip the pins to the side of the hole, so that the hole is fully visible.

Reel is now free to slide either forward or backward. Try to slide both ends of the reel at the same time to prevent the reel from binding. If binding occurs, loosen the four centering bolts on the reel arm braces. This should relieve pressure from brackets. If necessary tap reel mount with a block of wood and a hammer. Lock pin holes are located 2" apart on the reel arm.



Illustration 90: Fore-aft Lock Pin - Offset

Honey Bee Manufacturing Ltd. John Deere 4990-4995 WS Swather – Operator's Manual

After reel has been located in the desired position, insert lock pins through the hole in mount bracket and reel arm, making sure they are securely locked into reel arm. Set reel mount brackets in the same hole on each reel arm. Tighten any bolts that were loosened.



Illustration 91: Fore-aft Pin - Set in Place

Reel Arm Leveling and Height Adjustment

To level reels correctly, the reel adjustment brackets (adjuster nut) must be mounted in the proper position on the reel arms.

Each adjuster nut should be placed in holes #2 and #3 from the front for the Universal Harvester UII Pickup Reel, Hart Carter Pickup Reel and Honey Bee Bat Reel.



Illustration 92: Reel Arm - Detail View

Honey Bee Manufacturing Ltd.

Honey Bee

John Deere 4990-4995 WS Swather – Operator's Manual

If the reel arms need more adjusting, each reel arm can be adjusted separately by turning the reel adjuster screws.

Remove pin holding cylinder lock in place. Pivot cylinder lock downward so it can be rotated easily.

Measure the amount the reel needs to be adjusted.

Rotate cylinder lock clockwise if the arm needs to be lowered, and counter clockwise if it needs to be raised.

Pin cylinder lock back into the storage position when the reel is level.



Illustration 93: Reel Arm - Cylinder Lock

Hint: If the reel is lifted all the way up, leveled, then dropped down to half way, it will be easier to rotate the cylinder lock. Adjust the reel by the amount previously measured.

Center Arm Leveling

To level the center reel arm on swathers with dual reels adjust as follows.

- 1. Loosen the lock nut.
- 2. Turn bolt to adjust height.
- 3. Re-tighten lock nut.



Illustration 94: Center Arm Height Adjustment



Optional Hydraulic Fore & Aft

Swathers equipped with optional hydraulic fore and aft are operated using in-cab controls. Windrower must have fore/aft option or optional hydraulic solenoid kit must be installed to operate fore & aft cylinders.

The fore and aft hydraulic circuit should be plumbed according to the diagram on the right.

To extend the reel on the single reel circuit, the oil flows from the windrower to the barrel end of the 78A master cylinder on the right side. Oil from the rod end of this cylinder flows to the rod end of the 78A cylinder on the left side. Oil from the barrel end of the left cylinder then returns.



Illustration 95: Fore-aft Circuit - Single Reel

To retract the reel, the flow is reversed.

The double reel fore and aft circuit uses three identical cylinders. To extend the reel, oil from the windrower flows to the barrel end of the right hand cylinder, to the rod end of the center cylinder, to the barrel end of the left hand cylinder. Oil from the rod end of the left-hand cylinder returns to the windrower.

To retract the reel, oil flow is reversed.



Illustration 96: Fore Aft Circuit - Double Reel

Honey Bee Manufacturing Ltd. John Deere 4990-4995 WS Swather – Operator's Manual

Reel Centering



Illustration 97: Reel End Clearance - Right Side

Measure the clearance from the end shield on the reel to the crop divider on each end of the swather. If the reel is not centered on the swather, loosen the two bolts on both the left and right reel arm braces. Push the reel left or right until centered. Re-tighten all bolts.



Illustration 98: Reel End Clearance - Left Side



Illustration 99: Reel Brace Bolt Locations



Honey Bee Manufacturing Ltd. John Deere 4990-4995 WS Swather – Operator's Manual

Reel Drive

The reel is driven by a hydraulic motor with a direct drive coupler to the reel. Check coupler bolts and motor mount bolts regularly for tightness.



Illustration 100: Reel Drive Coupler

Check alignment of motor to reel tube, shim mounting bolts if required.



Illustration 101: Reel Motor Mounting Bolts



Reel Speed Adjustment

Normally reel speed is 10% to 20% faster than the ground speed of the windrower.

The windrower is equipped with standard reel speed control. The swather is configured with a flow control valve and a remote control motor on the table. The flow control regulates the oil flow, which governs the speed of the reel.

The flow control is also equipped with a relief valve which is factory set at 2200 psi. Do not set higher or damage to reel or reel motor may result. When oil is bypassed over the relief, an audible squeal may be heard and the reel may stall in crop.

If adjustment of the relief is required, remove the cap over the relief adjustment screw, loosen the lock nut and turn screw clockwise to increase the pressure. Check reel operation after adjusting relief 1/4 turn. Do not adjust relief by more than 1/4 turn increments.

For more information on adjusting the relief pressure, please refer to the **Adjusting the Relief Pressure** section in the **Hydraulics** chapter.



Illustration 102: Remote Reel Speed Controller



Illustration 103: Motor-driven Flow Control



Universal Ull Pick up Reel

Tine Pitch Adjustment

The pitch of the tines may be adjusted by loosening bolts (shown at right) at BOTH ends of the reel and inserting a suitable tool in tube, and partially rotating the control ring assembly.

- To increase the pitch of the tines, turn in direction of reel rotation.
- To decrease the pitch of the tines, turn in opposite direction to reel rotation.

Adjust tine pitch initially so tines are perpendicular to the cutter bar. Too great a pitch causes the reel to carry the cut crop around the reel, because the tines do not release the crop after it is cut.

The pitch MUST be adjusted the SAME at BOTH ends of the reel.

The tine pitch is critical to the operation of the swather. Adjust the tines to suit your individual needs and make note of what works best for your conditions and crops.

In crops that are down or lodged, adjust reel so that center of reel is ahead of cutter bar. Adjust tines to be aggressive, lifting crop and dropping it onto the draper decks. If crop starts to wrap around reel, adjust tines to make the angle of attack less aggressive.



Illustration 104: Tine Pitch Adjustment Ring



Illustration 105: Tine Pitch - Less Aggressive



John Deere 4990-4995 WS Swather – Operator's Manual

Minimum Reel Height

Minimum reel height is determined by the position of the reel lift cylinders on the swather, the minimum (retracted) length of the reel lift cylinders, and the length of the adjusting screws on the lift cylinders.

A 2" (50mm) minimum clearance between the tips of the pickup reel tines and the cutter bar MUST be maintained with the reel lift cylinders in their fully retracted position. Inadequate clearance can result in damage to knife sections, guards, and reel tines.

Reel Position in "Down" Crops

The pickup reel height in down crops should be low so the tines lift the crop onto the cutter bar. The tines should be adjusted more aggressively, so they pick up the crop and lift it onto the cutter bar without carrying the crop around the reel.

The fore and aft position of the reel should be adjusted so the reel center tube is in front of the cutter bar so the crop is lifted before it gets to the cutter bar.



Care must be taken to assure that the reel tines do not come in contact with the cutter bar. Tine contact will cause damage to the knife sections, guards, and other cutter bar parts. At no time should the reel tines contact the ground. Contact with the ground or with rocks will cause damage to the tines, pivot points and stars.

Reel Position in Standing Crops

The reel height is correctly adjusted for standing crops when the bats of the reel contact the crop about midway between the cutoff point and the top.

The the reel should be positioned so the reel center tube is slightly ahead of the cutter bar. If the reel is too far forward, the crop will not be pushed against the cutter bar and a portion of the cut crop will fall to the ground. If the reel is too far back, the crop will be pushed down before it is cut and some of the heads will be missed.

Reel Speed

Reel speed is adjusted to match ground speed. The reel should turn approximately 10% - 20% faster than the windrower is traveling. Adjust the reel speed until it appears that the reel is "pulling" the windrower through the field.

If the reel speed is too slow, the crop will not be pushed against the cutter bar and a portion of

Honey Bee Manufacturing Ltd. John Deere 4990-4995 WS Swather – Operator's Manual

the cut crop will fall to the ground because the reel doesn't push it onto the draper.

If the reel speed is too fast, the head or seed pod may be shattered by the impact of the reel. The crop may be pushed down before it can be cut and the uncut grain will be left in the field.

Lubrication - Reel Shaft Bearings

Lubricate every 10 hours of operation (or daily) with multi-purpose lithium base type grease.

Lubricate using the grease fitting at each end of the reel shaft. On 36', 39', and 42' swathers additional grease fittings are on the center reel arm mounts.

Yearly, remove and examine the polymer liners in the control plate tubes and replace if worn.



Illustration 106: Reel Bearing Lubrication Point

Reel Tines

Tines are attached to the leading side of the reel bats with 1/4" bolts and nuts. Either spring steel or plastic (Delrin) tines may be installed.

Illustration 107: Steel Tines

STEEL TINES

Honey Bee Manufacturing Ltd. John Deere 4990-4995 WS Swather – Operator's Manual

Control Rings

The control ring assemblies each have three rollers mounted in adjusting slots. To compensate for wear to the control ring, the rollers may be adjusted outward in the slots so that all three rollers are lightly in contact with the control ring.

All three rollers at each end of the reel must be moved the same amount so that all three rollers are in the same relative position. Do not take up the slack by adjusting only one roller.



Illustration 108: Control Ring Rollers

Hart-Carter Reel (HCC)

Placement of the Reel on the Swather

The fore-aft feature can move the reel back and ahead approximately12" (300mm).

- Normally, in "down" crop, the the reel should be set further ahead.
- In standing crop, the further forward the reel is moved, the less efficiently it will deliver crop onto the knife.
- If using manual fore-aft, set the reel center forward the same amount on both ends.
- For hay crops, the reel should be centered over the cutter bar with minimum tine clearance.
- Adjust the reel arms so that the tine tips will clear the guards and sickle by between 1" (25mm) and 5" (127mm).
- Normally the more "down" the crop; the closer the tines should be placed to the cutter bar.

Honey Bee Manufacturing Ltd. John Deere 4990-4995 WS Swather – Operator's Manual



Illustration 109: Placement of the Reel and Tines



Always engage reel lift and table lift cylinder locks before working under or around a raised pickup reel. Do not rely on the windrower hydraulic system to support the reel or the swather. A rupture or leak in any part of the system could cause the table to drop abruptly, if these stops were not in place.

Hint: An initial lubrication of the plastic bat bearings with a light film of oil will improve break-in and enhance the service life of the bearings.



John Deere 4990-4995 WS Swather – Operator's Manual

HCC Check Points before Operation

All bolts are tight.
Tines clear the sickle as reel rotates. (Rotate the reel manually.)
Auxiliary fingers clear side shields.
Reel arms are aligned. (No bow in the bat shaft or pivot bracket bat assemblies.)
Pitch adjustment bolt is in the same location on both sides. (double eccentric reels only).
Grease fittings on each end, and at the center on double reels.

Tine Pitch Adjustment

Begin with a pitch of about 5 degrees as shown below.

- Too much pitch will cause the reel to wind with cut crop because the tines do not release the crop after it is cut.
- For hay crops, the tines should be nearly perpendicular to the cutter bar.



Illustration 110: HCC Tine Pitch Adjustment



John Deere 4990-4995 WS Swather – Operator's Manual

Reel Speed

Reel speed for a 42" diameter reel should be between 10 and 12 RPM for each mile per hour of machine ground speed. A 52" diameter reel should rotate at 8 to 10 RPM for each mile per hour of machine ground speed. The most effective reel speed may be somewhat higher for down crops than for standing crops.

- Too great a reel speed causes winding of reel with cut crop. The crop does not get the chance to fall away from the reel. High reel speeds may also cause stripping and shelling of uncut crop.
- Too slow a reel speed can cause wrapping of the reel with cut crop. In this case, cut grain falls forward onto the bats instead of onto the draper.
- For hay crops, the reel speed may be higher than for grain crops.

Crop Control at Ends of the Swather

- It is important that the crop is completely divided before it contacts the cutter bar; otherwise the crop will lodge on the ends of the swather and eventually will wind onto the ends of the reel.
- Auxiliary end fingers are standard equipment on reels to help control crop lodging and wrapping at the ends of the reel.
- If crop is building up between a split reel, the innermost fingers may be heated and slightly bent to help prevent crop from entering the gap.



Draper

Depending on the options purchased, there may be two or three lateral drapers on the table which move the crop to the centre opening. All drapers must be set, and maintained properly to perform well. Quick release adjusters with spring tensioning allow easy access for cleaning, and maintain proper draper tension.

Draper Installation

Unpack draper. Check size to ensure it correct for the size of the deck. Be sure to align the v-guide with the notched side of the roller toward the rear end of the swather. Place draper bundle on the top of deck runners, and unroll with the slats facing up.

Wrap draper around one of the rollers and feed draper into the bottom runner of the deck. The bottom runners will support the draper, and prevent it from hanging down.

Pull draper through bottom runner, and wrap around the other roller. Pull the ends of the draper together. Install a connector bar to close the joint.

The heads of the screws should be installed from the centre deck opening side. This helps prevent the crop being caught on the screws. Complete the installation by adjusting tension and tracking.



Illustration 111: Unpacking the Draper



Illustration 112: Feeding Draper onto Bottom Runner

Honey Bee Manufacturing Ltd.

John Deere 4990-4995 WS Swather – Operator's Manual

Tension

Proper tension must be maintained on the draper to prevent slipping on the drive rollers. The draper tension is changed by adjusting the drive roller of each deck.

Attention! Draper tension should be just enough to prevent slipping. Do not overtighten as it may cause failure to the bearings, draper rollers and/ or draper belts.

- 1. Lower the swather to the ground.
- 2. Raise the reel to its maximum height and place the locks on the reel lift cylinders to prevent reel from falling.
- Loosen the lock nut if required. Release the tension with the quick release lever. Pull the roller evenly from the side of the swather to stretch the draper. Slide the adjuster clevis to compress the tension spring. Complete tightening by over-centering the quick release lever.
- 4. Restart the windrower and repeat the running test. If tracking is good, leave the lock nut loose.



Illustration 113: Draper Tension Adjustment

NOTE: When adjusting the draper tension and tracking, check the clearance between the draper deck slats and the end strut.

The draper may be damaged if it, or deck parts contact the end strut. A minimum of 2" (50 mm) clearance is recommended. If necessary, loosen the deck restrainer and slide deck over.

Alignment

The draper must track properly on the rollers to avoid damage to the draper. The decks allow approximately 1/4" of clearance on each side.

Lower the swather to the ground.

Raise the reel to its maximum height and place the locks on the reel lift cylinders.

Engage the swather drive with the engine at low idle.

Observe from the cab how the drapers are tracking.

If adjustment is required, shut down the swather, and turn off the engine.

Honey Bee Manufacturing Ltd.

Honey Bee

John Deere 4990-4995 WS Swather – Operator's Manual



Engage the brake on the windrower, shut the engine down, and wait for all moving parts to stop before leaving the cab.

Idler Roller Tracking Adjustment

This roller is fixed at the cutter bar, so is adjustable only at the back panel. If the draper is tracking toward the back panel, tighten the nut on the eye bolt (shorten the eye bolt). This will push the idler mount plate and idler roller at the back panel end out, creating more slack in the draper at the cutter bar.

If the draper tracks toward the cutter bar, lengthen the eye bolt. This will pull the idler mount plate and idler roller in, creating slack in the draper at the back panel end.



With quick release tensioning, the motor mount plate is normally left loose. To adjust the tracking at this end the lock nut holding the motor mount plate in place will need to be tightened. When the motor mount plate is tight, the back panel end of the drive roller will be fixed and the cutter bar end will be adjustable.

Adjust the spring tension as needed by sliding the Clevis and lock on the adjuster rod. If the roller does not move easily, tapping the motor housing with a rubber mallet will help the roller to move.

Re-test the tracking by running the swather at engine low idle.

Shut the swather down, turn the engine off, and wait for all moving parts to stop before leaving the cab.

Once the roller is tracking properly, loosen the lock bolt.







Illustration 115: Tracking Adjustment – Drive Roller



Honey Bee Manufacturing Ltd.

John Deere 4990-4995 WS Swather – Operator's Manual

Draper Speed

Proper draper speed is critical to the performance of your Grain Belt Swather. The draper speed should be set to match the field speed of the swather and to deliver the material smoothly to the centre opening. The speed of the lateral draper is controlled by an adjustable flow control. Adjusting the flow control will affect decks equally.

Double Swath Option

The spool flow divider splits the oil flow between the draper and the reel. If installed, the junior deck receives oil from the reel circuit. A fine adjustment screw on the flow divider can be used to vary the speed of the drapers or the reel to suit the conditions. Remove cap, turn adjustment screw with a flat blade screw driver. As flow in one circuit increases, the other will decrease.

Centre Single Swath

Draper motors are plumbed to one side of the flow divider. The other is for the reel motor.

When swathing, the draper speed should be set to form a good windrow, removing material from the cutter bar, and delivering the material smoothly to the opening.

Experiment with various draper speeds to determine the best swath formation for the existing cutting conditions. It may be necessary to make further adjustments as crop and moisture conditions change.

Attention! Excessive draper speed will cause abnormal wear, and will shorten the service life of the draper.

NOTE: The flow divider has a fine adjustment screw which can be used to adjust the flow to a limited degree. As one circuit increases the other will decrease.



Illustration 116: Hydraulic Flow Control Location





John Deere 4990-4995 WS Swather – Operator's Manual

Draper Splicing

Honey Bee Mfg. strives to provide top quality draper material on their products. Our draper is made from rubberized polyester with fiberglass reinforced slats. Regular maintenance will extend the life of your draper. Proper tension and tracking are very important. If material builds up inside the deck, it will wrap around the idler and drive rollers causing the draper to tighten. As the draper tightens, additional stress is put on the motor and the draper. If this condition is not corrected, it will result in failure of the drive roller motor or the draper. Tears in the draper can be caused by poor tracking, foreign materials, or from careless use. If only a portion of draper is damaged, a splice may be installed.

Before beginning this repair, you will need an additional connector bar set and a section of draper that is at least 2 ¹/₂" longer than the piece to be removed.

NOTE: If the damaged section is not near an existing connector bar, you will need 2 connector bar sets and a piece of draper 5" longer than the damaged piece.

- 1. Raise swather table and install lift cylinder locks. (If this is too high for comfortable access, the table can be set on blocks or lowered to the ground.)
- 2. Raise the reel and place the locks on the reel lift cylinders to prevent the reel from falling.



Engage the park brake on the windrower, shut the engine down, and wait for all moving parts to stop before leaving the cab.

- 3. Release the draper tension.
- 4. Remove draper connecting bar.
- 5. Correct the cause of the draper failure.
- 6. The draper should be cut midway between two slats to provide ample material for the new join. With a measuring tape, measure, and mark a line six inches from a slat on a good portion of the draper. Place a board directly under the line you have marked, to support the section you will be cutting. With a utility knife and a straight edge cut the draper along the marks. *This cut must be accurate, and square, to assure that the draper will track properly.* Repeat this step on the other side of the damaged area.
- 7. Lay the piece you have removed flat, and measure the width, then add 3 1/2 inches. The total will be the length of material you require for the splice. (If you need two new connector bar sets, add 5".)

Honey Bee Manufacturing Ltd.



John Deere 4990-4995 WS Swather – Operator's Manual



Illustration 117: Draper Splice Measurements

- 8. To mark the location for connector bar holes, measure 1" in from each edge to be joined, and mark a line parallel to the cut edges.
- 9. On each of these lines, measure 1-1/8" from the front edge of the draper, and make a mark for the first hole.
- 10. Drill 3/16" holes through each of these marks.



Illustration 118: Draper Connector Bar Installation

- 11. Place the backs of the draper together, lining up these drilled holes.
- 12. Place a connector bar on each side, line up the holes, and secure with a machine screw and nut.
- 13. Match up the edges of the draper and drill a hole at the opposite end on the 1" line, using the connector bar as a template. Insert a screw and secure in place. Drill the remaining holes through the holes in the connector bar, insert screws and secure.
- 14. Adjust draper tension. Trim all joins to 1/2" above connector bar.
- 15. Adjust tracking.

Idler Roller Removal

- 1. Relieve the tension from the draper.
- 2. Remove the nut that holds the eye bolt and the draper idler plate in place.
- 3. Remove idler plate from deck.
- 4. Remove spacer from bolt.
- 5. Pull idler roller out of deck.
- 6. Check bearings on each end and remove any material build up on roller.
- 7. Re-assemble in reverse order.



Illustration 119: Idler Roller Removal

NOTE: The spacer in step 4 <u>must</u> be re-installed for the idler plate to function.



Drive Roller Removal

- 1. Ensure lock nut on the motor mount adjuster plate is loose.
- 2. Release quick tension lever.
- 3. Loosen lock nuts on adjuster screw. Back off nuts about 3/4". Slide sleeve and spring down adjuster screw. Lift adjuster screw out of adjuster plate.
- 4. Mark hydraulic hoses on draper motor. Remove hoses. Insert plugs into hoses and caps on the motor to reduce oil loss and to prevent contamination.



Illustration 120: Drive Roller Removal

- 5. Remove the lock nut from the adjuster plate.
- 6. Pull adjuster plate, motor, and drive roller out of deck.
- 7. Check bearing in end of roller, and remove any build up of material on roller.

HINT: Check and remove any build up of material from the draper deck runners. If necessary, split draper at connector bar to gain access to the inside of the deck.

To re-install drive roller, reverse above procedure. Adjust tension and tracking.

Honey Bee Manufacturing Ltd. John Deere 4990-4995 WS Swather – Operator's Manual

Removing Draper motor

- 1. Remove Hex Bolt set screws.
- Insert two pry bars one on each side of motor, and pry motor out of drive roller.
 Do not hammer on the housing flanges of the motor. Damage to motor will void warranty.
- If motor does not move, insert a 7/8" or 3/4" rod through the center of drive roller and apply force directly to the shaft of the motor.



Illustration 121: Removing Draper Motor

Installing Draper Motor

- 1. Clean motor shaft and hub of drive roller. Apply anti-seize to shaft.
- 2. Insert key in motor shaft.



Illustration 122: Installing Shaft Key



Honey Bee Manufacturing Ltd. John Deere 4990-4995 WS Swather – Operator's Manual

 Insert motor into hub, lining key on shaft with the key-way in the hub. Do not use a hammer on housing flange; damage of this nature to the motor will void warranty. Use a soft blow or rubber hammer to apply force to end of motor.



4. Tighten set screws.

Illustration 123: Drive Roller Hub Key-way - End View

Draper Deck Maintenance:

- Remove draper connector bar.
- Remove draper clean draper of debris, both sides.
- Store draper indoors.
- Clean debris from rollers, deck channels, and runners.
- Check and bend down corners of deck runners so draper does not get caught.
- Clean adjusters; lubricate guide tubes and adjuster tubes. Adjusters should move freely inside the guide tube.
- Check idler roller bearings; they should spin freely.
- Check drive roller bearings.
- Check bearing stubs.

NOTE: If you elect to store the swather outside with draper installed, position the connector bar on the underside to aid water drainage. Ice build up underneath could cause draper to sag and drop out of the lower runner. If this is not noticed and corrected, damage may occur to draper on start-up.



John Deere 4990-4995 WS Swather – Operator's Manual

Cutting System

All cutter bar components must be maintained in good condition to obtain acceptable field performance. Inspect the cutter bar daily for damaged and broken parts before starting work. Repair or replace parts as required.





Illustration 124: Knife Section Warning Label



Honey Bee Manufacturing Ltd. John Deere 4990-4995 WS Swather – Operator's Manual

Removing the Knife

Remove the two socket head cap screws (1) on the knife head block. Slide the knife out of the cutter bar.

Reverse the procedure when installing the knife. Apply a small amount of thread lock solution to cap screws (1) before installation. Torque to recommended specifications - 59 ft-lb (80 Nm)



Illustration 125: Knife Removal

Guards

EasyCut guards are manufactured from heat treated spring steel with beveled cutting edges at the top and bottom which make the guards cut well and last longer.

When replacing guards always mount the new guard with the **SCH** stamp to the top. Be sure the spacer bar is on top of the cutter bar. The crimp-lock nut on the guard bolt should always be on top. Alignment is critical. Before tightening the guard bolts, push the spacer bar as far back on the cutter bar as possible and pull the guard ahead as far as possible. Sight down the cutter bar to be sure the guards are aligned. Tighten guard bolts.

Sickle Sections

The sickle sections of the knife are installed with alternating cutting surfaces. One section will have the cutting surface on the top and the next will have the cutting surface on the bottom. They must be in good condition to obtain proper cutting.

Replace a Section:

- 1. Remove the guard to expose the section.
- 2. Unbolt the section and install a new one.
- 3. Tighten the section bolts and nuts.
- 4. Install the guard.


OR:

- 1. Turn the knife by hand until one section bolt is exposed.
- 2. Remove the bolt.
- 3. Turn the knife until the other bolt is exposed.
- 4. Remove it, and install a new section by reversing this procedure.
- 5. Tighten section bolts and nuts.

Important: Always alternate the sickle sections, one with the servations facing up, the next, facing down.



Illustration 126: Sickle Sections - Top and Side Views



Knife Drive/Knife Head

Proper maintenance of the knife drive and the knife head is critical to the performance of your swather.

Check the knife drive hold down bolts daily. Tighten to the specified torque as needed.

Check the knife head bearing daily. If the bearing is loose, check the tightness of the bolt. If the bolt is tight, check the condition of the bearing and sleeve. If any parts are defective, replace them immediately to avoid damage to the drive.

Check the knife head locking bolt and the socket head cap screws daily. Rotate the knife drive by hand after tightening the knife head bolt to be sure the bearings rotate freely.

Check the knife head bolts which attach the knife head to the knife back daily. The bolts should be tightened to 120 in lbs., (13.5 Nm), (9.96 ft lbs.)



Illustration 127: Knife Drive Details



Illustration 128: Knife Head



Connector Bar

On some models of Honey Bee swathers a connector bar is used to join two sections of knife back. The sickle sections are bolted to the knife back. The connector bar is attached to the underside of the knife back with eight threaded inserts installed into the bar which protrude slightly on the side that contacts the knife back. The knife back is punched with slightly tapered holes to accommodate the sickle sections. The knife sections must be installed on the top side of the knife back (the side stamped "TOP") so that the protruding inserts of the connector bar will fit snugly into the tapered section holes. As the section bolts are tightened, the inserts in the connector bar are drawn into the knife back forcing them to clamp down on the bolt. The bolts should be tightened to 120 - 150 in-lbs, (13.5 - 17 Nm).



Illustration 129: Connector Bar Installation - Exploded View

Do not grind the inserts flush with the connector bar. This will defeat their function, and may cause a knife failure.

Cross section of shoulder insert, connector bar, knife back, sickle section, and bolt. Notice how the shoulder insert protrudes into the backup bar.

Check tightness of bolts daily; replace broken and worn sections as required.



Illustration 130: Knife Section - Cutaway View

Honey Bee

Honey Bee Manufacturing Ltd. John Deere 4990-4995 WS Swather – Operator's Manual

Overlap Kit

The overlap kit is used on swathers equipped with double knife drives. The fasteners in the overlapping portion of the knife are countersunk to provide a smooth-sliding surface. The overlap guards are open on top, and are deeper to provide room for the double thickness of the knife. The overlap strap bolted to the left-hand knife will slide over the countersunk sections where the knives overlap. If knives are noisy or are over heating, check to see if the overlap guards have been properly installed.

The knife sections that are on the overlap strap and the right hand knife back need to be snugged down to the back up bar when the countersink bolts are tight.



Illustration 131: Knife Overlap Section - Exploded View

If the sections are loose:

- 1. Remove the countersink bolts.
- Inspect the holes drilled into the knife back or overlap strap for a countersunk depression. This allows the tapered head of the bolt to draw down fully, seating in the knife section.
- If no countersink is found, drill them in (about 1/32" deep) with a 9/32" drill bit.



Illustration 132: Knife Back Insert



Repair Broken Knife Back

If the knife breaks during use, repairs can usually be made using a connector bar. Typically, the knife back will break across a sickle section bolt hole. The damaged section needs to be cut out and/or a section of knife removed. If the knife breaks close to the knife head end, remove that section of knife, reconnect the knife head, then add the new piece to the far end of the knife where there is less mechanical stress on the knife.

The join must be directly under the center of a sickle section, not where two sickle sections join.

Inspect the knife for dull/damaged guards and sections and built up crop residues. These are the most common causes of knife breakage.

Correct any of these cause factors before resuming operation.



Illustration 133: Knife Repair -Exploded View



Knife Speed Sensor

The table is equipped with a sensor, located on the knife drive motor, which provides the ability to monitor and calibrate knife speed.

The sensor should be positioned so that there is a gap of 1/16" between the pulse wheel and the sensor.



Illustration 134: Knife Speed Sensor

Monitoring Knife Speed

Knife speed can be displayed on the control panel in the cab of the power unit.

The reel speed option on this panel is now used to select the knife speed function.



Illustration 135: Control Panel



Leveling

The swather is attached to the windrower by one upper suspension link (Top Link) and two lift boot assemblies which slide onto the lift arms of the windrower. The top link adjusts the forward angle of the table. This adjustment affects the angle of the cutter bar in relationship to the ground.

Forward Angle Adjustment

Honey Bee

- 1. Loosen lock tab on the top link. With a suitable size rod, turn top link clockwise to tilt swather back, counter-clockwise to tilt swather forward.
- 2. Re-tighten lock tab once the desired swather angle has been reached.



Illustration 136: Adjusting the Manual Lift Link

Production Swather - Hydraulic Tilt Kit

The Honeybee Swather has an optional hydraulic control system for the swather tilt function.

The kit includes everything required for installing the system.



Table Angle

These views of the windrower and table show the results of adjustments to the top link.

This Illustration shows the top link fully retracted, drawing the top of the table back. The draper decks will run more horizontal to the ground.

This Illustration shows the top link fully extended, tilting the table forward. The draper decks will run at a steeper angle to the ground.





Caution!	Do not extend the top link beyond 3.25" of thread exposed at each end. Over-extending the top link may result in the table suddenly tipping forward.
	Retracted, the top link measures 17-1/2", extended, it measures 24".

Remember that the above examples represent the extreme range of adjustment. Experiment within this range to determine the best setting for your operating conditions and for the type of swath you want.



HINTS:	In rocky conditions, with a short crop, it may be beneficial to keep the guard tips up. Try shortening the top link.		
	In bushy crops, such as mustard, you may want to tip the swather forward to maximize the opening.		

Table Leveling

- 1. Park the unit on a smooth, level surface.
- 2. Ensure the tires are all at equal pressure.
- Equalize the angles of the extensions on the lift arms. Increasing or decreasing the number of threads exposed above the nuts will raise and lower the outer ends of the lift arms. In most cases, an equal number of threads on each bolt will equalize the height of the lift-arm ends.
- Begin by exposing ½ inch of thread past the nut on all four bolts. Increase or decrease the thread numbers protruding above the nuts to level the extensions. Work in small increments to ensure you do not over-correct.



Illustration 139: Lift Arms - Swather Removed

Important! To ensure full strength, do not reduce the number of exposed threads above the nuts to less than 2. The thread count above the nuts on an individual arm should be the same to ensure even clamping.



John Deere 4990-4995 WS Swather – Operator's Manual

Adjusting Table Float

Use the lightest float setting, that will keep the table from bouncing, while allowing it to follow uneven ground without gouging or scraping.

NOTE: If the platform has been raised for any length of time, it may lower slowly or may not lower all the way to the ground. This is due to the temperature difference in the accumulator. Once the platform has been lowered and temperatures equalize, the float will function normally.

If the windrower does not maintain float pressure, check the needle valve on the side of the high pressure valve, it must be closed. Refer to owneroperators manual.

Park swather on level ground, lower platform and set engine speed at operating rpm.

Float pressure is displayed in increments of 100 psi. On later models, pressure is displayed in increments of 10 psi.

- 1. Press platform float function (B) on the digital tachometer.
- 2. Press and release '+' on the float switch until platform starts to move upward.
- 3. Back off the psi reading, on the digital display (A), 100 psi by pressing and releasing '-' on the float switch.
- 4. Raise and lower the swather table several times.
- 5. With the swather table on the ground, stop the engine.
- 6. Check the platform float by lifting at each end of the table. Normally it should require less than 150 lbs. (68kg) to lift the end of the table.
- 7. Adjust float pressure as needed and repeat steps 5 through 7 until desired float pressure is attained.





NOTE:Once the platform has been set, the system will retain the setting after the
swather has been stopped.Refer to your owner operator's manual for more detailed information on the
operation of the JD 4990/JD 4995 Self Propelled Windrower.

Honey Bee Manufacturing Ltd.



John Deere 4990-4995 WS Swather – Operator's Manual

Preparing the table for further Leveling

If the table requires further leveling, you have 3 options that can be completed individually or in combination:

Caution! Park the windrower on a hard, level surface, and engage the park brake.

If the hitch end of the swather is low, this condition may be due to the weight of the hitch. Raise the swather to the fully raised position, shut the unit down, and wait for all moving parts to stop. Lock the platform in the fully raised position.

Option 1 - Remove transport hitch

Park the windrower on a hard, level surface, and engage the park brake.

Raise the table to its maximum height, and engage the platform lock.

Release the lock pin and remove the hitch from the draw bar tube.

Lower the hitch tube by removing the forward hitch mounting pin.

Carefully, remove the pin on the strut holding the other end of the transport to the table. Allow the hitch to fall to the ground.

Caution! - Hitch parts are heavy!



Illustration 140: Hitch Drawbar



Illustration 141: Hitch Sleeve - Viewed from below

Honey Bee Manufacturing Ltd.

Honey Bee

John Deere 4990-4995 WS Swather – Operator's Manual

Option 2 - Switch the lift arm float cylinders

Before you begin this option, refer to the table on the following page for important recommendations.

Before mounting the table to the windrower, swap the left (3.00×10.00) and right (2.75×10.00) hand cylinders. The larger cylinder will compensate with the extra power to lift the right side of the table evenly.

The cylinders have different sized hoses flowing to and from the windrower. Fittings will need to be changed.

Make the connections as shown, using the components listed below, which correspond to the numbers in the diagram.

- 1 6MF-8MB
- 2 6MB-8FB
- 3 8MB-10MF-90°
- 4 8MB-8MF-90°

 $5 - 6MB-8MF-90^{\circ}$ (from rod-end port of 2.75 inch cylinder.)



Illustration 142: Lift Arm Cylinders -Standard Orientation



Illustration 143: Lift Cylinder Hose Connections

Important Please study the following information prior to starting any work on either the windrower or the table to determine whether the windrower lift-arm cylinders require changes. If changes are required, completing them at this point will result in savings of time in equipment setup.

JD Windrower Float Cylinder Recommendation with Honey Bee

	No Hitch	Hitch	Float Pressure
18'	Swap Cylinders	No Change	Approximately 1200 psi at cutting height
21'	Swap Cylinders	No Change	Approximately 1250 psi at cutting height
25'	Swap Cylinders	No Change	Approximately 1500 psi at cutting height
30'	Swap Cylinders	No Change	Approximately 1700 psi at cutting height
*36'	Swap Cylinders	No Change	Approximately 1900 psi at cutting height

Single Knife / Double Knife - Single Swath

Single Knife / Double Knife - Double Swath

	No Hitch	Hitch	Float Pressure
18'	N/A	N/A	N/A
21'	Swap Cylinders	No Change	Approximately 1250 psi at cutting height
25'	Swap Cylinders	No Change	Approximately 1500 psi at cutting height
30'	Swap Cylinders	No Change	Approximately 1700 psi at cutting height
36'	N/A	N/A	N/A

***NOTE:** For 36' Double knife with hitch, floatation may be improved by replacing the 2 3/4" cylinder with another 3" cylinder with 1900 psi float pressure.

Option 3 - Adjust the set screw on the float cylinders

At the top of the float cylinders on both lift arms, there is a bolt used to set the point from which the cylinder lifts on the windrower.

Adjust these screws, alternately raising the low side and lowering the high side, until the swather sits level.



Illustration 144: Float Cylinder Set Screw



This Page Is Intentionally Left Blank



John Deere 4990-4995 WS Swather – Operator's Manual

Hydraulics

The Grain Belt Swather uses windrower hydraulics to power the various systems. The rate of oil flow from the windrower must be reduced to provide a maximum of 700 rpm for the knife drive. Hydraulic pressure from the windrower flows to the knife drive, then to a flow divider which supplies pressure to the draper and reel circuits. The system is protected by a pressure relief valve which should be set at 3000 psi. Return-flow oil is filtered before returning to the windrower.

NOTE : JD 4990/4995 windrowers require the pump to be de-stroked to 19.5 gpm (74 lpm).

Flow Divider

One side of the flow divider supplies a 10 gpm (37.8 lpm) flow control for the drapers, while the other side supplies a 20 gpm (75.6 lpm) flow control for the reel. The "CF" (control flow) port of the draper flow control goes to the draper motors. The "CF" (control flow) port of the reel flow control goes to the reel motor. The "EF" (excess flow) port of both flow controllers diverts oil directly to the return circuit.

Both flow controls are adjusted electrically from the cab.



The windrower relief valve is set to 5000 psi. Care must be used when working around pressurized hydraulic systems.

Quick couplers must be securely connected before the windrower is started, and power is applied to the swather. Serious injury, and/or damage to equipment may result from poor connections.

Honey Bee

Hydraulic Connection Points

Connect the hydraulic hoses from the windrower to the couplers shown below.

Operating Pressure - Knife Circuit

The pressure gauge, located on the manifold block, indicates the total hydraulic pressure required to run the knife, reel, and draper.

Normal operating pressure should range between 1500 and 2000 psi when the windrower is operating at normal working rpm, and the oil is at operating temperature.

It is normal for pressure to fluctuate while cutting, due to changing crop conditions. Other factors that will affect pressure include



the condition of the cutting system, and ground *Illustration 145: Hydraulic Connection Points* speed.

To determine the pressure required to run the knife, subtract the draper and reel pressure readings (at the gauge located on the flow divider) from the manifold block reading. Alternatively, you may set the draper and reel flow controls to zero and read the pressure at the manifold block gauge. This reading will be slightly higher due to back-pressure generated from the flow controls.

NOTE: Double knife drive systems typically operate at 500 psi higher pressure.

Checking or Adjusting Knife Relief Pressure



Set the park brake, shut the engine down, and wait for all moving parts to stop before leaving cab.

Be certain all bystanders are away from the machine prior to engaging the pump. Only stall the knife long enough to obtain accurate readings. Prolonged operation in this condition could cause damage.

- 1. Jam a wood block tightly in the knife, between a guard and cutting section.
- 2. Restart windrower. Raise the reel, and insert the cylinder lock. Set the reel flow control to "0".
- 3. Engage the hydraulic pump drive, bring the engine rpm to the normal working range, and check the pressure on the gauge. If the reading is 3000 psi, shut the windrower



down, remove the wood block, and reel cylinder stop.

4. Reset the reel flow control.

If adjustments are required, shut the windrower down, and continue with the following:

- Locate the relief valve on the manifold block. Adjust the relief screw; turning clockwise will increase, and counterclockwise will decrease the pressure.
- 2. With the knife jammed as described previously, restart the windrower, engage the hydraulic pump drive, and re-check the pressure reading.
- 3. Repeat as necessary to get 3000 psi reading.



Illustration 146: Relief Valve Location

Flow Control Setting.

There is a separate hydraulic flow control for both the draper and reel, however they should both be set the same way.

With the stop bolt on the flow control pointed to the CF port or the 0 (Zero) setting, the groove on the adjustment should be pointed towards the 10 (Ten).

The location of the flow control for the draper and the reel hydraulic systems is described on the following pages.



Illustration 147: Flow Control Setting



Draper Relief Pressure

The draper circuit flow control is equipped with a relief valve, preset to 2200 psi (151.5). If an excessive amount of oil is passing over the relief, a squeal may be heard, and the drapers may stall.

Adjusting Relief Pressure

Locate the flow control, behind the speed control box. See the illustration shown to the right for reference.

Remove the cap (acorn nut) over the relief

adjustment screw, loosen the lock nut, and

pressure.

turn of adjustment.

turn the screw clockwise to increase the relief

Re-check the draper operation after each 1/4



Illustration 148: Draper Speed Control

Cap Lock Nut

Illustration 149: Draper Flow Control

NOTE:	Normal operating pressure for the draper circuit, with warm oil, and the flow control set at eight, should be within 1200-2000 psi (124-137 bar).
Caution!	Setting the draper relief pressure too high may cause damage if a foreign object gets caught in the mechanism.

Honey Bee

Honey Bee Manufacturing Ltd. John Deere 4990-4995 WS Swather – Operator's Manual

Reel Speed Control

Reel speed is controlled by an electric motor attached to a 20 gpm (75.7 lpm) flow control. The motor is actuated by a switch in the cab.



Illustration 150: Reel Speed Control

Additional Reel Speed Control

Oil flow to the reel is supplied from the 50/50 flow divider.

If more reel speed is required, and the reel flow control is at maximum, the flow divider can be adjusted to divert more oil to the reel. Remove the acorn nut, and turn the adjusting screw to increase the oil flow to the reel. *Increasing reel speed using the flow divider will result in an equal reduction in draper speed.*

To Draper

Illustration 151: Flow Divider

Reel Relief Pressure

The flow control for the reel speed circuit, is equipped with a relief valve, factory preset at 2200 psi (124 bar). If excessive oil is passing over the relief valve, a squealing noise may be heard, or the reel may stall.

Honey Bee

Adjusting the Relief Pressure

Remove the cap (acorn nut) over the relief adjustment screw, loosen the lock nut, and turn the screw clockwise to increase the relief pressure.

Re-check reel operation after each 1/4 turn of adjustment.

Increasing the relief pressure will not increase reel speed.

Caution: Setting the reel relief pressure too high may cause damage if it contacts a solid object.

Return Line Filter

This filter cleans the oil as it returns to the windrower. Change this filter after the first 50 hours of operation, and seasonally thereafter.

A partially plugged oil filter can adversely affect the flow of oil in the system.



Illustration 152: Reel Flow Control



Illustration 153: Return Oil Filter

Hydraulic System Schematics

Draper Drive

Hydraulic Schematic Symbols - Draper Drive



Honey Bee

Honey Bee Manufacturing Ltd. John Deere 4990-4995 WS Swather – Operator's Manual

Draper Drive – Single Swath (WS Models)



Honey Bee

Honey Bee Manufacturing Ltd. John Deere 4990-4995 WS Swather – Operator's Manual

Draper Drive - Single Swath (WS Models)





Draper Drive: 21 - 36 ft Double Swath (WS Models)





Fore and Aft

Hydraulic Schematic Symbols – Fore and Aft



Fore & Aft Assembly - Split Reel (WS Models w/ Hydr. Solenoid Kit)





Fore & Aft Assembly - Solid Reel (WS Models w/ Hydr. Solenoid Kit)





Knife Drive

Hydraulic Schematic Symbols – Knife Drive





Single Knife - Drive





Double Knife - Drive





Reel Lift

Hydraulic Schematic Symbols – Reel Lift





Reel - Lift (Solid Reel)





Reel Lift (36 ft Solid Reel)





Reel - Lift (Split Reel)





Reel Drive Hydraulic Schematic Symbols – Reel Drive





Single Reel Drive – WS Models


Double Reel Drive (Series) - WS Models



Double Reel Drive (Parallel) - WS Models





Upper Tube Hydraulics

Hydraulic Schematic Symbols – Upper Tube Hydraulics





Upper Tube Hydraulics – Single Swath (WS Models w/Direct Block Drainage)





Upper Tube Hydraulics – Double Swath (WS Models w/Direct Block Drainage)





This Page Is Intentionally Left Blank



John Deere 4990-4995 WS Swather – Operator's Manual

Optional Equipment

Caster Gauge Wheels

The gauge wheels are part of the system that keeps the table aligned with the profile of the ground while cutting. They provide improved lateral flotation of the swather in rough and uneven ground conditions. The gauge wheels are designed to caster, so it is normally not necessary to raise the swather when cornering. The adjustment of the gauge wheel assembly relative to the cutting height is essential to effective terrain following.

Attention:	Lift the swather table and gauge wheels off the ground when backing up the windrower.			
	Damage to caster wheels can also result from making sharp turns with the windrower. The sharp turning radius of the windrower can cause one of the wheels to be dragged backwards, potentially causing damage to the wheel.			
Note:	The swather should be leveled and parked on level ground before attempting to adjust gauge wheel height.			

Gauge wheels must be adjusted with the knife set at field operating height. Normal

adjustment compresses the spring shafts of the gauge wheels approximately 1.5" (38mm) to 2.0" (50mm). Two adjustments are incorporated into the design of the gauge wheel assemblies.

- 1. Top-mount lugs on the back of the swather frame.
- 2. Screw type Jack with height indicator.

Gauge Wheel Height Adjustment

Honey Bee

- 1. Retract the gauge wheel jack to its lowest position, pointer should be above the "1" mark.
- 2. Set the gauge wheel into one of the mounting holes on the table (usually the second hole from the top).
- Adjust the swather table height until the cutter bar is at an average cutting height for the crop being cut. ie. desired stubble height.
- 4. Lower the gauge wheel assembly to the ground using the screw jack.
- 5. Repeat this procedure on the other gauge wheel assembly.
- Check the amount of compression on the spring shaft of the gauge wheel assemblies, if incorrect, repeat steps (1) thru (4) as described above until both springs are equally compressed within the specified amounts (1.5" (38mm) to 2.0" (50mm)).
- 7. It may be necessary to re-locate the pin in the top link to obtain satisfactory adjustment.



Illustration 154: Gauge Wheel Attachment



Illustration 155: Gauge Wheel Spring Shaft



Excessive compression of the spring tubes will add stress to the top link, causing premature wear.

Honey Bee		Honey Bee Manufacturing Ltd. John Deere 4990-4995 WS Swather – Operator's Manual	
Note:	Adjusting tabl compression wheels will be	able tilt, spring floatation, and pitch will affect the amount of In in the spring tubes. Further adjustments to the gauge be necessary.	
Important!	Gauge wheels table.	are not designed to support the weight of the swather	

End Strut Gauge Wheels

End strut gauge wheels are mounted at the outboard ends of the main table frame to enhance the ability to closely follow the contour of the ground with the cutter bar.

Holes drilled in the wheel mount provide height adjustment by relocating the axle shaft as needed.



Honey Bee Manufacturing Ltd.

Illustration 156: End Strut Gauge Wheel

Note:	The draper decks may need to be moved to allow at least 1" of clearance
	from the end strut gauge wheels, to avoid damage to the drapers.

Vertical Crop Cutters

Vertical crop cutters are offered by a variety of third party vendors. They are designed to cut in a vertical direction on for use in cutting entangled crops such as canola and peas and preventing the crop from being entangled on the ends of the cutting bar.

The crop cutters must operate in series from the last reel drive motor in the circuit. The circuit flows from the *last* reel motor return port to the power inlet of the left-hand crop cutter motor, to the power inlet of the right hand crop cutter motor to the main return line of the swather.

Honey Bee

Honey Bee Manufacturing Ltd. John Deere 4990-4995 WS Swather – Operator's Manual

Cross Auger

The cross auger can improve the cutting of specialty crops such as peas, canola, mustard, safflower, and lupins. Many of these crops are not heavy enough to keep them firmly on the draper. Bushy or crops with vines tend to slide on the draper, causing them to fall into the windrow in bunches or wads.

The left and right hand flighting on the cross auger gently pushes the crop down onto the draper, assisting its movement toward the windrow.

Some cross auger models include jacks where the cross auger mounts onto the frame. These jacks allow you to raise or lower the cross auger to account for different crop conditions.



Illustration 157: Cross Auger

The cross auger is plumbed into the draper circuit with a manual speed control (needle valve).

The rotation speed should be adjusted no faster than necessary to keep the crop moving evenly.

If set to rotate too quickly, the crop may wrap onto the flighting.



Illustration 158: Cross Auger Flow Control

The cross auger can be left in position even if it is not being used, such as when harvesting cereal grains. The cross auger can be turned off by fully opening the needle valve. Draper speed should not be affected.



Double Swath Option – 21, 25, 30 and 36 Foot Tables

Most Honey Bee Grain Belt Swathers can be equipped with a double swath option. This option allows the operator to lay two swaths. The first swath will be delivered to the opening on the right end of the swather. On the next round, the decks can be shifted to the right, creating an opening on the left end of the swather. This places the second swath beside the first. This option is useful in light crop conditions.

The decks are shifted using hydraulic motors activated by an electric solenoid on the selector valve.

The solenoid selector valve reverses the flow through the output ports when activated.

The deck shift motor and the draper motor are connected in parallel, so that when the deck arrives in its new position, the deck shift motor stops and the draper motor will be running in the opposite direction.



Illustration 159: Deck Shift System

The deck shift roller chains are located on the back of the rear panel.

Adjuster bolts at either end of the chain are used to adjust tension.

The chains should not have too much slack, nor should they be too tight.

Excess tension will cause the decks to warp.



Illustration 160: Roller Chain Tensioner

Honey Bee

Honey Bee Manufacturing Ltd. John Deere 4990-4995 WS Swather – Operator's Manual

Deck shift stops are installed on each chain. Before adjusting these stops, determine how much the deck needs to be shifted. Then move the appropriate stop.

To have a deck move further/less to the left, the right hand stop will need to be moved, conversely, for the deck to move further/less to the right, the left hand stop will need to be moved.



Illustration 161: Deck Shift Stops

The stop should be set so that the deck does not hit against the other draper decks or the swather frame. Allow approximately 1" of space between the decks.

Check all hose clearances on hydraulic motors after shifting the deck, to ensure they are not pinched or stretched.

Check draper tracking and adjust if required. See Draper Adjustment section of this manual for assistance.



Illustration 162: Setting Deck Gap



When shifting the deck for the double swath option, you must disconnect the cross auger motor from the hydraulic circuit using the quick couplers provided. The cross auger motor is connected in series with the draper motor, therefore the hydraulic lines will become damaged if the draper is moved while still connected to the cross auger motor.



Junior Deck Option – For Swathers With the Double Swath Option

When using the double swath option, the Jr. Deck can be installed on the far right hand side of the swather to move the swath away from the standing crop. This leaves a larger gap between the swaths.

The Jr. Deck can be left on the swather when single swath delivery is required, but will leave a narrower swath.

The Jr. Deck is easily removed if a wider swath is required.



Illustration 163: Jr. Deck

Steel Skid Plates

Steel skid plates are available for your swather unit as an add on option. They ensure your ability to hug the ground, without unnecessary wear to your swather.

These plates are located on the bottom of the cutter bar, bolted to the guard sections of the knife.



Illustration 164: Steel Skid Plate Location.

Dimensions – Single swath delivery

Honey Bee

Refer to the illustration below for the following dimensions:

Model (ft/m)	A (in/cm)	B (in/cm)	C (in/cm)
18HB (18/5.5)	80/208	50/130	80/208
21HB (21/6.4)	99/257	50/130	99/257
25HB (25/7.6)	104/270	80/208	104/270
	104/270	68/177	118/307*
	118/307*	56/146	118/307*
30HB (30/9.1)	136/354	80/208	136/354
	136/354	68/177	150/390*
	150/390*	56/146	150/390*
36HB (36/11)	175/450	80/208	175/450
	175/450	68/177	189/486*
	189/486*	56/146	189/486*

" Indicates the addition of one 14 deck	*	Indicates the addition of one 14" deck
---	---	--





John Deere 4990-4995 WS Swather – Operator's Manual

Dimensions – Double Swath Delivery

Refer to the illustration below for the following dimensions:

Model	A (in/cm)	B (in/cm)	C (in/cm)	D (in/cm)
21HB (21/6.4)	6/16	45/114	99/257	99/257
	-	50/130 (X)	99/257	99/257
25HB (25/7.6)	19/48	41/135 (J)	118/307	118/307
	6/16	54/140	118/307	118/307
	-	56/142 (X)	118/307	118/307
	-	68/172 (X)	118/307	104/264 *
	-	80/208 (X)	104/264 *	104/264 *
30HB (30/9.1)	19/48	37/121 (J)	150/390	150/390
	6/16	50/130	150/390	150/390
	-	56/142 (X)	150/390	150/390
	-	68/172 (X)	150/390	136/345 *
	-	80/208 (X)	136/345 *	136/345 *
36HB (36/10.9)	19/48	35/115 (J)	189/480	189/480
	6/16	48/158	189/480	189/480
	-	56/142 (X)	189/480	189/480
	-	68/172 (X)	189/480	175/445 *
	-	80/208 (X)	175/445 *	175/445 *

(X) - Indicates only available with centre delivery.

(J) - Indicates the addition of a junior deck.

* - Indicates the the removal of one 14" deck.



Honey Bee

John Deere 4990-4995 WS Swather – Operator's Manual

Draper Extension for Swathing

When swathing in light crop conditions, it may be necessary to narrow the opening in order to lay a tight swath. One option is to add the 14 inch deck extension kit to the idler end of a deck, and add to or replace the existing draper with a longer one.

- 1. Remove the connector bar and open the draper to expose the idler roller.
- 2. Remove the nut and washer that hold the idler adjuster plate in place.
- 3. Remove the idler plate, idler roller, and front adjuster.



Illustration 167: Idler Roller Details

- 4. Install the 14" back panel to the 14" extension deck.
- 5. Install extension deck and back panel onto the end of the deck being extended.
- 6. Install the front connecter and the rear deck connector.
- 7. Install the front adjuster, idler roller, and idler plate.
- 8. Join the 30" draper extension to the regular draper with a connector bar.



Illustration 168: Deck Extension Kit - Exploded View

- 9. Wrap draper around the rollers and connect ends together with the other connector bar.
- 10. Adjust draper tension and tracking.



Hay Guard / Short Crop Guard

The Hay Guard comes pre-punched for easy installation of self tapping (Tech) screws.

Lay out Hay Guard starting at the end of the cutter bar. Install the longest section at the ends. The hay guard/ short crop guard butt together end to end.

Remove the self tapping screw holding the tab of the crop deflector. The hay guard should fit tight against the rise of the cutter bar leaving approximately ½" clearance between the ribs of the draper and the underside of the hay guard.



Illustration 169: Self-Tapping Screw Locations



Do not over-torque self-tapping screws. Their hardened threads will quickly strip out the hole to oversize.

Secure tab through hay guard and into the cutter bar. Install remainder of bolts to hay guard.

Install the next section of hay guard, butting it up to the first section. Install self tapping screws to secure. Continue until all sections of hay guard are installed.

The hay guard profile is designed so the draper runs along the angle iron welded to the underside of the guard.

Honey Bee

Honey Bee Manufacturing Ltd. John Deere 4990-4995 WS Swather – Operator's Manual

SCH Crop Lifters

Install the lifter spools to the underside of the guards using the longer bolts supplied in the kit.

The spools should be spaced equally along the cutter bar, one per foot is recommended.



Illustration 170: Crop Lifters Installed

The socket of the lifter has three locking pin positions for adjusting the lifter angle.

The lock pin can be placed in any of the three holes.

For additional adjustment, flat washers can be added between the guard and the crop lifter spool.

For crop lifters to work properly the bottom runners must be parallel to the ground when the platform is in cutting position. The illustration to the right shows the correct position of a standard crop lifter.

The bottom runner of the Special Series lifter should be parallel to the ground. To find the correct setting of the lifters for a given platform, drive on to a smooth, flat surface. Mount one lifter in the middle of the platform. Position 1 Position 2 Position 3 Locking Pin Secured Spool

Illustration 171: Crop Lifter - Side Detail



Correct Position Incorrect Position Incorrect Position The crop lifter "Climbs" The crop lifter "digs"

Illustration 172: Crop Lifter Orientation



Illustration 173: Special Series Crop Lifter



Lower platform until crop lifter just touches the ground. The runner of the lifter should be parallel to the ground. If it is not, change lock pin positions and if necessary, vary number of flat washers until the correct position is achieved.

Hydraulic Tilt Cylinder Assembly

An option to the standard manual top- link is the hydraulic tilt cylinder which provides control of the table's angle from the cab of the windrower



Illustration 174: Hydraulic Tilt Cylinder

Switches for the platform tilt are located on the F-N-R lever and the adjacent control panel.



Illustration 175: F-N-R Control Switches



This Page Is Intentionally Left Blank



John Deere 4990-4995 WS Swather – Operator's Manual

Windrow Type

Several factors affect windrow formation: Ground speed, draper speed, type of crop, reel speed, table angle, and stubble height. This manual will give the operator some guidelines in how machine settings can affect windrow formation. It is the operator's responsibility to adjust the settings for the type of windrow desired.

Windrow Formations

Herringbone: The ideal formation for weathering and ease of pick up. The crop needs to be standing straight or leaning uniformly in one direction.

Parallel: A good windrow that is easier to form.

Angled Parallel (75 Degree Diagonal): A good windrow but not as good as the parallel.

Fan Tail: Good weathering ability and easy to pick up, but not as good as the first three types.

Diagonal (45 Degrees): This swath is less desirable, because the heads are concentrated on one side of the swath. It is more difficult to pick up and is more easily affected by wind or rain.

Dovetail: Also less desirable, because heads are concentrated in the middle of the swath. More difficult to pick up and more easily affected by wind or rain.

Ground Speed

Herringbone Parallel

Angled Parallel

Diagonal

Diagonal

Diagonal

Dovetall

Hustration 176: Swath Patterns

Use windrow quality as a guide to travel speed. Cut at lower speeds when terrain is rough and when crops are lodged or tangled. Excessive speed may be indicated by a ragged cut in the stubble.

Stubble Height

For most crops, best results are obtained when the table is adjusted for stubble height of 6" to 8" or (150 to 200 mm). This height should have enough strength to support the windrow and to provide air flow underneath to speed drying. Also, the windrow will be easier to pick up.



This Page Is Intentionally Left Blank



John Deere 4990-4995 WS Swather – Operator's Manual

Lubrication and Maintenance

Important!	Use good quality, general purpose grease.			
Component		Lubricant	Frequency/(Notes)	
Knife Drives			50 hours	
Knife head bearing		Grease	(grease fitting on bottom of crank shaft)	
Main bearing and gear		Grease	(grease fitting on side of knife drive)	
Knife		Diesel	Whenever knife is gummed, soak with diesel or	
			clean with a pressure washer	
Reel bearings		Grease	10 hours	
Gauge Whee	ls - King Pin	Grease	10 hours	
Gauge Wheel Jacks		Grease	50 hours	
Wheel Bearings		Grease	Disassemble and re-pack yearly.	
Hydraulic return line filter			(Change after first 50 hours of operation and seasonally thereafter.)	
			(Filter 27281 Donaldson - P 163419)	

The following maintenance decals and lubrication locations have been placed on your machine in the areas indicated. Please take this manual, walk around your machine and familiarize yourself with the lubrication locations and content of these decals. Review this information, with your machine operators. Please keep decals legible.



Illustration 177: Lubrication Points & Decal Locations



Maintenance Related Decals



Illustration 178: Grease every 10 hours of operation.



Illustration 179: Grease every 50 hours of operation.

4

2



Illustration 181: Canvas/Draper tension and tracking.





Illustration 180: Torque and Grease requirements for the knife drive.



Troubleshooting				
Problem	Possible Cause	Solution		
Reel				
Reel won't hold height.	Leaking hose or fitting.	Repair or replace.		
	Valve in windrower leaking.	See windrower Manual.		
Reel won't hold level.	Leaking hose or fitting.	Repair or replace.		
	Air in system.	Bleed slave cylinder.		
	Faulty master cylinder.	Repair or replace.		
Reel raises or lowers	Reel cylinders binding.	Replace cylinder.		
erratically	Arms bent or binding.	Repair or replace.		
	Low hydraulic oil.	See windrower Manual.		
Reel won't raise.	Hydraulic couplers don't match.	Install correct couplers.		
	Valve is not open.	0		
	Faulty windrower hydraulics.	Open Valve.		
	Reel not plumbed into tilt circuit.	See windrower Manual.		
		Check plumbing schematic.		
Damage to center of reel.	Reel set too low.	Adjust height.		
	Reel tube bent.	Replace.		
Reel hitting at end.	Reel not centered.	Adjust centering.		

Honey Bee

Honey Bee Manufacturing Ltd.

Problem	Possible Cause	Solution
Reel will not turn or turns	Flow control set too low.	Advance setting.
erratically.	Draper flow set too high.	Reduce draper speed.
	Faulty relief valve.	Clean or replace.
	Seized bearing(s).	Replace bearing(s).
	Faulty drive motor.	Replace motor.
	Reel Tied Down.	Release Reel.
Reel Speed cannot be	Poor electrical connection.	Check connections and cable.
adjusted.		Replace motor.
	Defective reel speed motor.	Replace.
	Circuit breaker open or burnt ou	t.
Knife		
Knife won't run.	Low hydraulic oil.	Add oil. Determine cause of oil loss.
	Cutter bar jammed.	Check for damaged guards or sections.
	Faulty drive motor.	Repair or replace motor.
	Faulty knife drive.	Repair or replace.
	Faulty hydraulic pump.	Repair or replace.
	Knife gummed.	Clean cutter bar.
Knife stalls easy.	Type of material being cut.	Reduce ground speed.
	Low pressure at knife motor.	Check system pressure.
	Bent guards or cutter bar.	Repair or replace.
	Faulty knife drive.	Check for loose crank shaft.
	Seized knife head bearing.	Replace.
	Knife head out of alignment.	Adjust knife head bearing.

Honey Bee

Problem	Possible Cause	Solution
Unloaded system pressure	Faulty draper motor.	Repair or replace.
too high.	Relief valve set too low (3000 psi).	Adjust.
	Relief valve stuck open.	Remove and clean or replace cartridge.
	Wrong type of hydraulic oil.	Change windrower hydraulic oil.
Knife running too slow.	Flow control set low.	Set control higher.
(700 rpm recommended)	Low oil level.	Add oil, locate cause and repair.
	Relief valve stuck open.	Remove and clean or replace cartridge.
	Low oil volume.	Reset volume, 19.5 gpm required.
	Wrong motor size.	Check with manufacturer.
	Worn pump or motor.	Repair or replace.
Excessive vibration.	Knife running too fast.	Check speed (700 rpm)
	Check oil volume (19.5 gpm)	Reset if needed.
	Loose bearings in drive.	Replace bearings.
	Loose knife head bolts.	Tighten.
	Damaged sickles or guards.	Replace.



Problem	Possible Cause	Solution
Excessive noise.	First guard bent or out of alignment.	Straighten or replace.
	Knife drive bearing faulty.	Replace.
	Knife drive loose.	Tighten bolts and check for damage to housing.
	Knife drive running too fast.	Set to 700 rpm.
	Knife head adjusted too high or too low.	Loosen clamp bolt on knife head bearing and adjust.
Knife leaves strip of crop	Excessive ground speed.	Slow down.
standing.	Bent or broken guard.	Straighten or replace.
	Broken knife section.	Replace.
	Plugged guard.	Clean.
Connector bar breaks	Damaged sections or guards.	Repair or replace.
	Knife gummed up.	Soak with diesel fuel, or wash with pressure washer.
	Sections on knife back installed on wrong side.	Tighten or replace.
		Remove sections, turn knife over and replace sections.
Knife head breaks	Section bolts not tight.	Tighten and/or replace bolts.
	Knife gummed up.	Soak with diesel fuel, or wash with pressure washer.
	Damaged sections or guards.	Repair and/or replace.
	Sickle sections dull.	
	Tough crop.	Replace sections.
	Knife drive running to fast.	Reduce ground speed.
		Check speed with photo tach.

Honey Bee

Problem	Possible Cause	Solution
Draper		
Draper not tracking straight.	Drive or idler roller out of alignment.	Adjust draper tracking.
	Draper splice not cut straight.	Re-punch connector bar holes in draper.
	material building up on rollers.	Clean rollers.
Draper slipping.	Draper too loose.	Adjust draper tension.
	Draper is snagging.	Check alignment. Look for obstructions.
Draper not turning.	Draper is snagged or caught.	Check for interference.
	Flow control is shut off.	Adjust flow control.
	Oil flow is being by-passed.	Check relief valve setting.
		Remove and clean relief cartridge.
Draper oil pressure in excess	sMaterial build up on rollers.	Clean rollers.
of 2200 psi.	Faulty bearing in roller.	Replace bearing.
	Faulty draper motor.	Check motor temperature, check for oil leaking from shaft seal.
		Replace motor.
Decks		
Decks creep sideways.	Restrainer tubes not installed or have fallen off.	Install or replace tubes.
Decks lift out of position.	Deck is not locked under rear edge of cutter bar.	Place deck in proper position.
	Hold down clips on back panels are loose or are not installed.	ngmen of replace.

Honey Bee

Problem	Possible Cause	Solution			
Decks will not shift.	Poor electrical connections.	Trace and repair.			
	Electrical cable not plugged into windrower or control box.	Check connections.			
	Decks or back panels jammed or binding.	Check decks and clean out debris.			
Heads shattering or breaking	g Reel speed too fast.	Reduce reel speed.			
off.	Ground speed too high.	Reduce ground speed.			
	Crop over-ripe.	Cut earlier in morning or late at night when humidity is higher.			
Cut grain falling off cutter	Reel set too high.	Lower reel.			
bar.	Table set too high.	Lower table.			
	Reel too slow for ground speed.	Increase reel speed.			
Does not pick up lodged	Table too high.	Lower table.			
crop.	Reel too high.	Lower reel.			
	Reel too far back.	Move reel forward.			
	Ground speed too fast for reel speed.	Reduce ground speed or increase reel speed.			
	Bat reel not suitable.	Install optional Pickup Reel.			
	Crop lying too flat for guards to pickup.	Install optional SCH Crop Lifters.			
Hydraulic Oil					
Temperature High	Excessive oil going over reliefs.	Check reliefs on flow controls.			
	Faulty pump or motors.	Repair or replace.			
	Draper too tight or not tracking.	Adjust draper alignment.			
	Oil too light.	Refill with correct grade.			

Honey Bee

John Deere 4990-4995 WS Swather – Operator's Manual

Problem	Possible Cause	Solution		
Leveling				
Swather not level.	Float pressure too low.	Adjust float pressure.		
Table Angle				
Draper running too flat or too steep.	Tilt (turnbuckle or hydraulic) out of adjustment.	Adjust.		
Raising and lowering the Swather				
Swather will not lift.	Windrower lift capacity.	Check system pressure.		
		Check the needle valve, table lift circuit.		
		Increase needle valve opening.		
Swather table lifts and lowers too slowly.	Needle valve set too low.	Adjust needle valve on lift circuit.		
Lift and Float Systems				
Platform Does Not Follow Ground Contour.	Platform float pressure too high, making platform feel light.	Check windrower operator's manual. Adjust float pressure.		
NOTE : If float pressure is se too high platform will feel	<i>t</i> Field/Road switch in the ROAD Position.	Set switch to FIELD position.		
light and bouncy. If float pressure is too low, platform	Faulty Relay.	Replace Relay.		
will feel heavy and unresponsive. It should require less than 150 lbs. to	Accumulator precharge pressure See your John Deere dealer. too low.			

lift the end of the platform.

Honey Bee

Problem	Possible Cause	Solution			
Platform Digs Into Ground and Pushes Hard.	Guards digging into ground.	Adjust guard angle, with turnbuckle or hydraulic tilt.			
	Platform float pressure too low, making platform feel too heavy.	Adjust float pressure.			
	Accumulator precharge pressure too high.	; See your John Deere Dealer			
Platform Drops Too Fast or Does Not Lower Smoothly	Platform float pressure too low, making platform too heavy.	Adjust platform float.			
	Accumulator precharge pressure	Adjust needle valve.			
Platform Will Not Lift or Lifts	Needle valve set too low.	Adjust needle valve.			
Too Slow	Binding lift linkage.	Replace bent or worn parts.			
	Platform float pressure too low, making platform too heavy.	Adjust platform Float.			
	Worn lift pump.				
	Low Relief valve setting.	See your John Deere dealer.			
	Excessive charge oil flow to	See your John Deere dealer. See your John Deere dealer.			
	pumps.				
	Faulty switch or relay.	D			
	Faulty solenoid or valve cartridge.	Replace.			

Specifications/Features

Weights

Weights are given in lbs/kg format.

Model	SP18	SP21	SP25	SP30	SP36	
Width	18'	21'	25'	30'	36'	
Weight	1792/815	1980/900	2280/1036	2710/1232	3207/1458	

Weight includes - Swather assembly c/w decks and attached hydraulic components.

Weight does not include - Double swath decks or lift arms.

Lift Arms – All models 200/91.

Component	SP18	SP21	SP25	SP30	SP36		
Pick-up Reel – Ull Universal							
Weight	490/223	562/255	624/283	720/327	980/446		
Pick-up Reel – HCC ML							
Weight	502/228	566/257	625/284	718/326	884/401		
Gauge Wheel Package							
Weight	N/A	N/A	136/62	125/57	125/57		
Knife Drive Availability							
- Single	standard	n/a	standard	standard	n/a		
- Double	optional	standard	optional	optional	standard		
Transport Axle/Hitch Tube Package – All models 206/93.							

Technical Specifications

Honey Bee

- Knife Drive - SCH epicyclic 3 5/16" stroke, hydraulically driven, 1100-1400 strokes per minute. (2 strokes = 1 RPM)

- Cutting System - SCH Easy Cut, spring steel guards and bolted sections.

- V-Guided Draper - 42" Rubberized polyester, fiberglass reinforced, tie bar connectors.

- Draper Speed adjustable in cab, 0-575 fpm.
- Reel Speed adjustable in cab.
- Cutting angle adjustable in cab.
- Standard single swath opening is approximately 81" +/- 3"
- Standard double swath opening is approximately 46" +/- 6"

- Swath opening may be decreased for WS25, WS30, WS36 tables by inserting 14" Deck extensions.

Note: Specifications are subject to change without notice or obligation.

Honey Bee

Honey Bee Manufacturing Ltd.

John Deere 4990-4995 WS Swather – Operator's Manual

Options

- Pickup Reel 6 bat, 42" diameter Universal U-II Pickup Reel, plastic fingers.
- Pickup Reel 6 bat, 44" diameter HCC Level-II Pickup Reel, plastic fingers
- Steel Fingers for U-II Pickup Reel.
- Fore/Aft Hydraulic reel adjustment
- Double Reel Drive
- End Strut Gauge Wheels
- Castoring Gauge Wheels without tires or wheels WS25 (Not offered for WS21 models)
- Steel Skid Plate (Not available for WS36)
- Hydraulic Tilt
- Quick Coupler Finishing Kit
- Junior Deck for Double Swath Tables.
- 14" Deck Extension Kit
- Cross Auger Kit (Not available for WS21)
- Swath Delivery Kits Hydraulic deck shift.
- Crop Lifters for cereals and/or specialty crops.

Included in the Standard Swather

- Storage Axle and Hitch
- Remote Canvas Speed Control
- Hay Guard
- UHMW Poly Skid Plate
- Warning Light Package
- Castoring Gauge Wheels WS30, WS36
- Tires/Wheels/Hubs/Spindles





John Deere 4990-4995 WS Swather – Operator's Manual

Bolt Torque

The tables shown below give correct torque values for various bolts and cap screws. Tighten all bolts to the torques specified in chart unless otherwise noted. Check tightness of bolts periodically, using bolt torque chart as a guide. Always replace fasteners with the same strength rating and size.

Unified Torque Specifications				Metric Torque Specifications									
Grade	SA	E 5	SAE 8		SAE 8		SAE 8		Grade	Grade 8.8		10.9	
Size:	N.m	Lb-ft	N.m	Lb-ft	Size:	N.m	Lb-ft	N.m	Lb-ft				
1/4"	12	9	17	12	M6	11	8.5	17	12				
5/16"	25	19	36	27	M8	28	20	40	30				
3/8"	45	33	63	45	M10	55	40	80	60				
7/16"	72	53	100	75	M12	95	70	140	105				
1/2"	110	80	155	115	M14	150	110	225	165				
9/16"	155	115	220	165	M16	240	175	350	255				
5/8"	215	160	305	220	M18	330	250	475	350				
3/4"	390	290	540	400	M20	475	350	675	500				
7/8"	570	420	880	650	M22	650	475	925	675				
1"	915	675	1320	970	M24	825	600	1150	850				

* Torque figures indicated above are valid for non-greased or non-oiled threads and heads unless otherwise specified. Therefore, do not grease or oil bolts or cap screws unless otherwise specified in this manual. When using locking elements, increase torque values by 5%




John Deere 4990-4995 WS Swather – Operator's Manual

Hydraulic Fitting Torque

Tightening Flare Type Tube Fittings

- 1. Check flare and flare seat for defects that might cause leakage.
- 2. Align tube with fitting before tightening.
- 3. Lubricate connection and hand tighten swivel nut until snug.
- 4. To prevent twisting the tube(s), use two wrenches. Place one wrench on the connector body and with the second tighten the swivel nut to the torque shown.

** The torque values shown are based on lubricated connections as will be found in reassembly.

Tube OD Size, inch	Nut Size, inch	Torque Value, N.m	Torque Value, lb-ft	Flats to tighten	Turns to tighten
3/16	7/16	8	6	1	1/6
1/4	9/16	12	9	1	1/6
5/16	5/8	16	12	1	1/6
3/8	11/16	24	18	1	1/6
1/2	7/8	46	34	1	1/6
5/8	1	62	46	1	1/6
3/4	1-1/4	102	75	3/4	1/8
7/8	1-3/8	122	90	3/4	1/8

Hydraulic Fitting Torque Table



Honey Bee Manufacturing Ltd. John Deere 4990-4995 WS Swather – Operator's Manual

Tightening O-ring Fittings

- 1. Inspect O-ring and seat for dirt or obvious defects.
- 2. On angle fittings, back the lock nut off until washer bottoms out at top of groove.
- 3. Hand tighten fitting until back-up washer or washer face (if straight fitting) bottoms on face and O-ring is seated.
- 4. Position angle fittings by unscrewing no more than one turn.
- 5. Tighten straight fittings to torque shown.
- 6. Tighten angle fittings to torque shown while holding body of fitting with a wrench.

OD Thread Size - inch	Nut Size - inch	Torque Value - N.m	Torque Value - Ib-ft	Flats to tighten	Turns to tighten
3/8	1/2	8	6	2	1/3
7/16	9/16	12	9	2	1/3
1/2	5/8	16	12	2	1/3
9/16	11/16	24	18	2	1/3
3/4	7/8	46	34	2	1/3
7/8	1	62	46	1-1/2	1/4
1-1/16	1-1/4	102	75	1	1/6
1-3/16	1-3/8	122	90	1	1/6
1-5/16	1-1/2	142	105	3/4	1/8
1-5/8	1-7/8	190	140	3/4	1/8
1-7/8	2-1/8	217	160	1/2	1/12

*The torque values shown are based on lubricated connections as will be found in reassembly.



John Deere 4990-4995 WS Swather – Operator's Manual

Lighting

The lighting system incorporates two circuits: See Illustration 182: Lighting - Main components, page 182, and Illustration 185: Hazard Warning - Color Codes, page 185.

- 1. Transport running lights. Items # 3, 4, 6.
- 2. Warning flashers. Items # 1, 2, 5.

Transport Lights:

- 1. The transport lights consist of two wiring harnesses and two (tail, signal, and stop) lights.
- 2. The 46ft (14.03M) Harness extension with a male (Universal Trailer Connector, 4 Pole) leads to the towing vehicle. It is the transporters' responsibility to ensure proper connection to towing vehicle.
- 3. The 6ft (1.83M) Harness wishbone with male (Universal Trailer Connector, 4 Pole) that connects to the female end of the 46 ft (14.03M) extension harness. The plugs on the other end connect directly to the pig tail of the lights.

Warning Lights:

- 1. The warning flasher light wiring consists of a 10 ft (3.05M) pigtail harness that attaches from the windrower to the warning flasher harness. The adaptor plug (JD 7 way connector) is installed at factory with the reel speed wiring plug.
- 2. The warning flasher harness is a total of 45 ft (13.73M) in length and connects the warning flasher lights to the windrower.



Illustration 182: Lighting - Main components

Honey Bee Manufacturing Ltd.

John Deere 4990-4995 WS Swather – Operator's Manual



Harness 6ft Wishbone

Illustration 183: Wiring Harnesses



Honey Bee Manufacturing Ltd. John Deere 4990-4995 WS Swather – Operator's Manual

Light Wiring

The lights operate on two circuits:

- 1. Transport running lights.
- 2. Warning flashers.

TRANSPORT LIGHTS:

Transport lights should be used at all times when the header is towed on public roads. Connect to the towvehicle using the proper plugs.

Wiring color code:

- White Ground
- Brown Tail Lamps
- Green Right Hand Stop / Turn signal
- Yellow Left Hand Stop / Turn signal





When transporting the swather while it is mounted to the windrower, hazard warning lights must be connected and operating. The amber warning lamps must be visible from both the front and the rear.

Wiring Layout:

- White Ground
- Green Right Flasher
- Yellow Left Flasher



Be Seen. Be Safe!



Honey Bee Manufacturing Ltd. John Deere 4990-4995 WS Swather – Operator's Manual

Index of Illustrations

Illustration 1: General Information - Directions23
Illustration 2: Swather Adapter Kit Components24
Illustration 3: Quick Coupler Fittings - detail
Illustration 4: Tilt Cylinder Couplers28
Illustration 5: Windshield Guard29
Illustration 6: Wire Clip29
Illustration 7: Manual Lift Link - Exploded View
Illustration 8: Hydraulic Tilt Cylinder - Exploded View
Illustration 9: Hydraulic Tilt Valve Assembly
Illustration 10: 4990-4995 Lift Link Bracket 33
Illustration 11: Hydraulic Tilt Cylinder - Storage Position
Illustration 12: Wiring Bracket - Exploded View
Illustration 13: Bracket Installation Complete
Illustration 14: Needle Valve Mounting Bracket
Illustration 15: Needle-Valve bracket in position
Illustration 16: Needle Valve and Hydraulic Control Block
Illustration 17: Needle Valve - Exploded View

Illustration 18: Needle Valve - Non-STC Threaded Fittings
Illustration 19: Hydraulic Control Block38
Illustration 20: Needle Valve
Illustration 21: Bracket40
Illustration 22: Wiring Harness Clip40
Illustration 23: Access to Rear Electrical Panel40
Illustration 24: 31-pin Plug41
Illustration 25: Plug Location41
Illustration 26: 4995 Switch Panel41
Illustration 27: Electrical Panel - Float Relay
Illustration 28: 4990 Switch Panel43
Illustration 29: 4995 - Suggested Switch Locations44
Illustration 30: Suggested Switch Placement
Illustration 31: Console Modification45
Illustration 32: Console Cutting Template45
Illustration 33: Hole Location46
Illustration 34: Wiring Installation Complete
Illustration 35: Hole Location - Closeup View
Illustration 36: Wiring Panel Access47
Illustration 37: Lift Arm Extension48

•

Honey Bee Manufacturing Ltd.

ohn Deere 4990-4995	WS Swather –	Operator's	Manual
---------------------	--------------	-------------------	--------

Illustration 38: Lift Arm Assembly Complete
Illustration 39: Crop Divider- Exploded View
Illustration 40: Crop Divider Complete50
Illustration 41: Installation of Strut Rollers51
Illustration 42: Securing the Base Plate Roller
Illustration 43: Hose Connected to Swather
Illustration 44: Hose Hanger - Close-up View
Illustration 45: Hose in Storage Position52
Illustration 46: Swather on Transport Unit53
Illustration 47: Wheel Assembly Removed.53
Illustration 48: Positioning the Windrower54
Illustration 49: Lifting the Extension Arm54
Illustration 50: Left Roller Engaged54
Illustration 51: Right Roller Engaged54
Illustration 52: Left Roller Pin Installation top view
Illustration 53: Right Roller Pin Installation bottom view55
Illustration 54: Safety Chain & Hydraulic Tilt
Illustration 55: Manual Lift Link56
Illustration 56: Windrower Table Lock56
Illustration 57: Securing the Tilt Cylinder56
Illustration 58: Axle Tube Retraction

Illustration 59: Axle Tube Retracted57
Illustration 60: Axle in road Position58
Illustration 61: Axle in Field Position58
Illustration 62: Windrower-Swather Connections59
Illustration 63: Main Hydraulic Connections
Illustration 64: Hitch Components60
Illustration 65: Jack In Stored Position60
Illustration 66: Removing the Jack60
Illustration 67: Tachometer61
Illustration 68: Pump Adjuster Mounting Bracket63
Illustration 69: Pump Adjuster Assembly Complete63
Illustration 70: New JD 4895/4995 Wiring Schematic66
Illustration 71: Original JD 4895/4995 Wiring Schematic67
Illustration 72: Original JD 4890/4990 Wiring Schematic68
Illustration 73: Unlocking the Platform69
Illustration 74: F-N-R Lever Controls70
Illustration 75: Reel Cylinder at Full Extension70
Illustration 76: Bleed Port Location71
Illustration 77: Single Reel - Lift Circuit71
Illustration 78: Double Reel - Lift Circuit72
Illustration 79: 36' Single Reel Lift72

Honey Bee Manufacturing Ltd. John Deere 4990-4995 WS Swather – Operator's Manual

Illustration 80: Transport Electrical	
Connector	Illustration 102: Remote Reel Speed Controller87
Storage76	Illustration 103: Motor-driven Flow Control 87
Illustration 82: Hitch Tube Extended, Jack Installed76	Illustration 104: Tine Pitch Adjustment Ring
Illustration 83: Transport Axle Lowered77	Illustration 105: Tine Pitch - Less Aggressive
Illustration 84: Axle Extended77	
Illustration 85: Axle Jack in Position78	Illustration 106: Reel Bearing Lubrication
Illustration 86: Removing the Hitch Pins78	Point90
Illustration 87: Removing Hydraulic Link78	Illustration 107: Steel Tines90
Illustration 88: Storing the Lift Link	Illustration 108: Control Ring Rollers91
Illustration 89: Axle Ready for Transport79	Illustration 109: Placement of the Reel and Tines92
Illustration 90: Center Arm Height Adjustment81	Illustration 110: HCC Tine Pitch Adjustment
Illustration 91: Fore-aft Lock Pin - Offset82	Illustration 111: Unpacking the Draper95
Illustration 92: Fore-aft Pin - Set in Place82	Illustration 112: Feeding Draper onto Bottom
Illustration 93: Reel Arm - Detail View83	Runner
Illustration 94: Reel Arm - Cylinder Lock83	Illustration 113: Draper Tension Adjustment
Illustration 95: Fore-aft Circuit - Single Reel 	Illustration 114: Tracking Adjustment - Idler
Illustration 96: Fore Aft Circuit - Dual Reel.84	Illustration 115: Tracking Adjustment – Drive
Illustration 97: Reel End Clearance - Right Side	Roller
Illustration 98: Reel End Clearance - Left	Illustration 116: Hydraulic Flow Control Location98
Illustration 99: Reel Brace Bolt Locations85	Illustration 117: Draper Splice Measurements100
Illustration 100: Reel Drive Coupler	Illustration 118: Draper Connector Bar
Illustration 101: Reel Motor Mounting Bolts	Installation100

Honey Bee Manufacturing Ltd. John Deere 4990-4995 WS Swather – Operator's Manual

Illustration 119: Idler Roller Removal1	01
Illustration 120: Drive Roller Removal1	02
Illustration 121: Removing Draper Motor. 1	03
Illustration 122: Installing Shaft Key1	03
Illustration 123: Drive Roller Hub Key-way End View1	- 04
Illustration 124: Knife Section Warning Lab	oel 05
Illustration 125: Knife Removal1	06
Illustration 126: Sickle Sections - Top and Side Views1	07
Illustration 127: Knife Drive Details1	80
Illustration 128: Knife Head1	80
Illustration 129: Connector Bar Installation Exploded View1	- 09
Illustration 130: Knife Section - Cutaway View1	09
Illustration 131: Knife Overlap Section - Exploded View1	10
Illustration 132: Knife Back Insert1	10
Illustration 133: Knife Repair - Exploded View1	111
Illustration 134: Knife Speed Sensor1	12
Illustration 135: Control Panel1	12
Illustration 136: Adjusting the Manual Lift Link1	13
Illustration 137: Table Angle - Top-link Shortened1	14
Illustration 138: Table Angle - Top-link Extended1	14

Illustration 139: Lift Arms - Swather Removed115
Illustration 140: Hitch Drawbar117
Illustration 141: Hitch Sleeve - Viewed from below117
Illustration 142: Lift Arm Cylinders - Standard Orientation118
Illustration 143: Lift Cylinder Hose Connections118
Illustration 144: Float Cylinder Set Screw 119
Illustration 145: Hydraulic Connection Points
Illustration 146: Relief Valve Location123
Illustration 147: Flow Control Setting123
Illustration 148: Draper Speed Control124
Illustration 149: Draper Flow Control124
Illustration 150: Reel Remote Controller - Location125
Illustration 151: Flow Divider125
Illustration 152: Reel Flow Control126
Illustration 153: Return Oil Filter126
Illustration 154: Gauge Wheel Attachment
Illustration 155: Gauge Wheel Spring Shaft150
Illustration 156: End Strut Gauge Wheel151
Illustration 157: Cross Auger152
Illustration 158: Cross Auger Flow Control
Illustration 159: Deck Shift System153

Honey Bee Manufacturing Ltd. John Deere 4990-4995 WS Swather – Operator's Manual

Illustration 160: Roller Chain Tensioner153
Illustration 161: Deck Shift Stops154
Illustration 162: Setting Deck Gap154
Illustration 163: Jr. Deck155
Illustration 164: Steel Skid Plate Location.
Illustration 165: Single Swath Delivery156
Illustration 166: Double Swath Delivery157
Illustration 167: Idler Roller Details158
Illustration 168: Deck Extension Kit - Exploded View158
Illustration 169: Self-Tapping Screw Locations159
Illustration 170: Crop Lifters Installed160
Illustration 171: Crop Lifter - Side Detail160
Illustration 172: Crop Lifter Orientation160
Illustration 173: Special Series Crop Lifter

Illustration 174: Hydraulic Tilt Cylinder	161
Illustration 175: F-N-R Control Switches	161
Illustration 176: Swath Patterns	163
Illustration 177: Lubrication Points & Deca Locations	al 165
Illustration 178: Grease every 10 hours of operation	166
Illustration 179: Grease every 50 hours of operation	166
Illustration 180: Torque and Grease requirements for the knife drive	166
Illustration 181: Canvas/Draper tension a tracking	nd 166
Illustration 182: Lighting - Main componer	าts 182
Illustration 183: Wiring Harnesses	183
Illustration 184: Lights - Wiring Color Cod	es 184
Illustration 185: Hazard Warning - Color Codes	185

Honey Bee Manufacturing Ltd. Box 120 Frontier, Saskatchewan SON-OWO

> Tel (306) 296-2297 Fax (306) 296-2165

www.honeybee.ca e-mail info@honeybee.ca

> Revision 05 Issued Jan. 2008 Printed in Canada